

LR-3/MARKSMAN STANDARD CHARGER - LONGSHOT TARGET CAMERAS LR-3/MARKSMAN STANDARD CHARGER

[Optics & Mounting](#) > [Action Cameras](#) > [Accessories](#)

Though the LONGSHOT LR-3 and Marksman target-camera systems have built-in batteries that last for 12 hours, there's always the chance that your range session will go longer! Plus, ranges that have these cameras set up for multi-day shoots need to get batteries refreshed and ready to roll again as quickly as possible, so that's why the company rolled out this 12V DC Battery Charger! The design works with the lithium-ion batteries on board the LONGSHOT cameras and charges quickly.



Attributes

- Name: [LONGSHOT TARGET CAMERAS LR-3/MARKSMAN STANDARD CHARGER](#)
- Manufacturer: [LONGSHOT TARGET CAMERAS](#)
- Product no.: 100038720
- Mfr. No.: TV-AC100
- Delivery weight: 0.086kg
- Shipping height: 51mm
- Shipping width: 89mm
- Shipping length: 140mm
- UPC: 649070997638

Table of Contents

- Startpage
- Safety Instruction Guide for LR3/MARKSMAN STANDARD CHARGER
- About Us

Safety Instruction Guide for LR3/MARKSMAN STANDARD CHARGER

Introduction

Thank you for choosing the LR3/MARKSMAN STANDARD CHARGER for your LONGSHOT targetcamera systems. This guide provides essential safety information to ensure the safe and effective use of the charger. Please read this guide carefully before using the product.

General Safety Guidelines

- Always follow the manufacturer's instructions for safe use.
- Ensure that the charger is used only with compatible LONGSHOT lithiumion batteries.
- Keep the charger and batteries out of reach of children and pets.
- Regularly inspect the charger for any signs of damage. Do not use if damaged.
- Avoid exposure to moisture, extreme temperatures, and direct sunlight.
- Do not attempt to repair or modify the charger.

Specific Safety Precautions for Use

- Use the charger in a wellventilated area to prevent overheating.
- Do not use the charger if it has been dropped or damaged.
- Avoid shortcircuiting the charger or battery terminals.
- Do not leave the charger unattended while in use.
- Disconnect the charger from the power source when not in use.
- Ensure that the power outlet is compatible with the charger specifications.

Instructions for Installation and Usage

1. Installation:

- Place the charger on a stable, flat surface away from flammable materials.
- Ensure the charger is plugged into a compatible 12V DC power outlet.

2. Charging the Battery:

- Insert the LONGSHOT lithiumion battery into the charger, ensuring proper alignment.
- The charger will indicate when charging has begun (refer to the charger's indicator lights).
- Allow the battery to charge fully before use. Charging time may vary based on battery condition.

3. Removing the Battery:

- Once charging is complete, disconnect the charger from the power source.
- Carefully remove the battery from the charger, avoiding contact with metal terminals.

4. Storage:

- Store the charger in a cool, dry place when not in use.
- Keep the charger and batteries in their original packaging if possible.

Disposal Instructions

- Dispose of the charger and batteries in accordance with local regulations for electronic waste.

- Do not throw batteries in general waste. Check for designated battery recycling programs in your area.

Contact Information for Further Support

For any inquiries regarding safety, usage, or other concerns, please refer to the manufacturer's customer support resources.

Important Note: This guide is intended to enhance safety and ensure compliance with the EU General Product Safety Regulation (GPSR). Please report any unsafe products or accidents to the appropriate authorities and stay informed about recall updates through the EU's Safety Gate platform. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk