

AR-15 EJECTOR SPRING - BRN AR-15 SAFETY SELECTOR/BOLT EJECTOR SPRING, SILVER

OEM AR-15/M16 replacement Ejector Spring.



Attributes

- Name: BRN AR-15 SAFETY SELECTOR/BOLT EJECTOR SPRING, SILVER
- Manufacturer: BROWNELLS
- Product no.: 100040960
- Mfr. No.: AZ-0008
- Make: AR-15
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029651

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: AR15 Ejector Spring Safety Instruction Guide](#)
- [Français: Instructions de sécurité pour le ressort d'éjecteur AR15 BROWNELLS](#)

AR15 Ejector Spring Safety Instruction Guide

Introduction

Thank you for purchasing the AR15 Ejector Spring by Brownells. This guide provides essential safety instructions, installation guidelines, and proper usage information to ensure a safe and effective experience with your product. Please read this manual thoroughly before use.

General Safety Guidelines

- Always use the AR15 Ejector Spring in accordance with the manufacturer's instructions.
- Ensure that the product is compatible with your specific firearm model.
- Regularly inspect the Ejector Spring for wear or damage before each use.
- Store the Ejector Spring in a dry, cool place away from direct sunlight and moisture.
- Keep the Ejector Spring out of reach of children and unauthorized users.
- Report any unsafe conditions or accidents involving this product to the appropriate authorities.

Specific Safety Precautions for Use

- Do not modify the Ejector Spring in any way, as this may compromise safety and functionality.
- Wear appropriate safety gear, such as eye protection, when handling or installing the Ejector Spring.
- Ensure that the firearm is unloaded and pointed in a safe direction during installation.
- Avoid using the Ejector Spring if it shows signs of damage, such as bending or corrosion.
- Always follow local laws and regulations regarding firearm accessories.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a punch tool and a hammer.

2. Installation

- Remove the bolt carrier group from the upper receiver of your AR15.
- Locate the existing Ejector Spring and carefully remove it using the punch tool.
- Insert the new AR15 Ejector Spring into the appropriate slot, ensuring it is seated correctly.
- Reassemble the bolt carrier group and ensure it functions properly.

3. Usage

- Test the firearm in a safe environment to ensure proper functionality of the Ejector Spring.
- Regularly check the Ejector Spring during routine maintenance to ensure it remains in good condition.

Disposal Instructions

- Dispose of the Ejector Spring in accordance with local regulations.
- Do not dispose of the Ejector Spring in regular household waste if it is damaged or worn.
- Contact your local waste management authority for guidance on safe disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the AR15 Ejector Spring, please refer to the manufacturer's website or customer support for assistance.

Thank you for prioritizing safety and compliance while using the AR15 Ejector Spring. Your attention to these guidelines helps ensure a safe and enjoyable experience.

Instructions de sécurité pour le ressort d'éjecteur AR15 BROWNELLS

Introduction

Merci d'avoir choisi le ressort d'éjecteur AR15 BROWNELLS. Ce guide est conçu pour vous fournir des informations essentielles sur la sécurité, l'utilisation et l'élimination de ce produit. Veuillez lire attentivement toutes les sections afin d'assurer une utilisation sécurisée et efficace.

Directives générales de sécurité

- Assurez-vous de toujours utiliser le ressort d'éjecteur conformément aux instructions fournies.
- Vérifiez régulièrement l'état du ressort avant chaque utilisation pour détecter tout signe d'usure ou de dommage.
- Rangez le produit hors de portée des enfants et des animaux domestiques.
- Ne modifiez pas le ressort d'éjecteur. Toute modification peut compromettre la sécurité et la fonctionnalité du produit.
- Si vous remarquez des anomalies lors de l'utilisation, cessez immédiatement l'utilisation et consultez un professionnel.

Précautions de sécurité spécifiques à l'utilisation

- Utilisez toujours des équipements de protection individuelle appropriés lors de l'installation et de l'utilisation du ressort.
- Ne jamais utiliser le ressort d'éjecteur dans des conditions humides ou mouillées.
- Assurez-vous que l'AR15 est déchargé avant d'installer ou de remplacer le ressort d'éjecteur.
- Ne pas forcer le ressort lors de l'installation. Un ajustement incorrect peut entraîner des blessures.
- Suivez toutes les lois et réglementations locales concernant l'utilisation des armes à feu.

Instructions pour l'installation et l'utilisation

1. Préparation:

- Assurez-vous que l'AR15 est complètement déchargé.
- Rassemblez tous les outils nécessaires pour l'installation.

2. Installation:

- Retirez l'ancienne pièce (ressort d'éjecteur) en suivant les instructions du fabricant.
- Insérez le nouveau ressort d'éjecteur en vous assurant qu'il est correctement positionné.
- Vérifiez que le ressort est bien en place et qu'il fonctionne correctement.

3. Utilisation:

- Testez le fonctionnement de l'éjecteur après l'installation pour vous assurer qu'il fonctionne comme prévu.
- Utilisez l'AR15 conformément aux instructions du fabricant et aux lois en vigueur.

Instructions d'élimination

- Ne jetez pas le ressort d'éjecteur à la poubelle ordinaire.
- Consultez les réglementations locales concernant l'élimination des pièces d'armement.
- Si possible, apportez le ressort d'éjecteur à un centre de recyclage spécialisé.

Informations de contact pour un support supplémentaire

Pour toute question ou préoccupation concernant la sécurité ou l'utilisation de ce produit, veuillez contacter le service client du fabricant ou consulter leur site web pour plus d'informations.