

DOUBLE SCOPED RIFLE CASE - SINGLE SCOPED RIFLE CASE 51" BLACK

[Shooting Accessories](#) > [Gun Storage](#) > [Gun Cases](#)

The newest offering in the MTM Rifle Case lineup is a double version of the Scoped Rifle Case. It is designed to hold two rifles or shotguns up to 50.5 inches long, wide enough for scoped models. The Double Scoped Rifle Case is molded from specially formulated, high-impact plastic. It is designed with four hinges and kept securely latched by four strong snap latches. For added security, four lock points are located next to each latch. Rifles are held secure during transport via a set of quality convoluted foam.



Attributes

- Name: [SINGLE SCOPED RIFLE CASE 51" BLACK](#)
- Manufacturer: [MTM CASE-GARD](#)
- Product no.: 100041691
- Mfr. No.: RC51
- Color: Black
- Material: Polymer
- Size: 51
- Style: Rifle
- Delivery weight: 4.536kg
- Shipping height: 108mm
- Shipping width: 318mm
- Shipping length: 1,334mm
- UPC: 026057262406

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DOUBLE SCOPED RIFLE CASE
- About Us

Safety Instruction Guide for DOUBLE SCOPED RIFLE CASE

Introduction

Thank you for choosing the DOUBLE SCOPED RIFLE CASE. This product is designed to provide secure storage and transport for your rifles or shotguns. To ensure your safety and the safety of others, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the case is used only for its intended purpose of storing and transporting firearms.
- Always check local laws and regulations regarding the transportation and storage of firearms.
- Keep the case away from children and unauthorized users.
- Regularly inspect the case for any signs of wear or damage. If any damage is found, discontinue use immediately.
- Use the case in a wellventilated area to avoid any buildup of harmful substances.
- Always secure the case properly when not in use to prevent unauthorized access.

Specific Safety Precautions for Use

- When loading or unloading firearms, ensure that they are pointed in a safe direction.
- Always verify that firearms are unloaded before placing them in the case.
- Do not exceed the recommended weight limit of the case to avoid damage or failure.
- Ensure that all latches and locks are secured before transporting the case.
- Avoid placing heavy objects on top of the case during transport.
- Use caution when handling the case to prevent pinching or crushing injuries.

Instructions for Installation and Usage

1. Unpacking the Case

- Carefully remove the DOUBLE SCOPED RIFLE CASE from its packaging.
- Inspect the case for any visible damage or defects.

2. Loading Firearms

- Open the case by releasing the snap latches.
- Place each rifle or shotgun into the case, ensuring that they are properly positioned and supported by the convoluted foam.
- Close the case and secure all latches firmly.

3. Transporting the Case

- When transporting, ensure that the case is held securely and is not dropped or subjected to impact.
- Use the lock points to secure the case if necessary, especially in transit.

4. Storing the Case

- Store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- Ensure that the case is kept out of reach of children and unauthorized individuals.

Disposal Instructions

- When the DOUBLE SCOPED RIFLE CASE is no longer needed, dispose of it responsibly.
- Check local regulations for disposal of plastic products.
- If possible, recycle the case according to local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the DOUBLE SCOPED RIFLE CASE, please refer to the manufacturer's contact information. Ensure you have the product details ready for a prompt response.

By following these guidelines, you can help ensure the safe use of your DOUBLE SCOPED RIFLE CASE. Thank you for your attention to safety and compliance with all relevant regulations.

About Us

Brownells Switzerland

Brownells Switzerland

www.brownells.ch