

# PUSH BUTTON QD SLING SWIVEL - BLUE FORCE GEAR PUSH BUTTON QD SLING SWIVEL 1.25"

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Tactical Sling Mounts](#)

The Push Button QD Sling Swivel provides a secure, quiet sling attachment point and allows slings to be quickly removed and installed on multiple weapons. The Push Button Sling Swivel can be threaded on to any Vickers Slings. The Blue Force Gear Push Button Sling Swivel was designed to be stronger and lighter than the common Push Button QD Swivels. The smaller swivel body and push button reduces weight while minimizing the chance of accidentally disengaging the swivel. A larger gauge sling loop gives increased strength and durability. The Push Button Quick Detach Sling Swivel has a matte phosphate finish for corrosion resistance and signature reduction. The Push Button Sling Swivels fit all common quick detach (QD Swivel) sockets found on some buttstocks, forends, rails, or aftermarket socket adapters. Ensure that your weapon has a QD socket to correctly attach the sling to the weapon. For attaching a Push Button Sling Swivel to railed forends without integral QD sockets, you can use the Rail Mounted Push Button Swivel Socket. For a true quick release sling swivel, see the RED Swivel - a push button swivel that is installed and removed by pulling on the emergency release knob. Contrary to push belief, the common QD swivel is not an emergency release point as the ""push then pull"" motion is fine motor skill and can be difficult with gloves or in stressful situations. \*\*\* Place a small drop of oil or gun lube down the push button channel every time you clean your weapon to ensure smooth operation and protect the internals from corrosion \*\*\* Choosing between 1" and 1.25" loops: 1" Swivels can be used on any Vickers Sling that has 1.25" webbing. The 1" loop keeps the Swivel more stationary on the sling. 1.25" Swivels can also be used on any Vickers Sling but allows for more movement of the webbing than the 1" Swivels



## Attributes

- Name: [BLUE FORCE GEAR PUSH BUTTON QD SLING SWIVEL 1.25"](#)
- Manufacturer: [BLUE FORCE GEAR](#)
- Product no.: 430100710
- Mfr. No.: PB-125
- Colour: Black
- Delivery weight: 0.259kg
- Shipping height: 6mm
- Shipping width: 38mm
- Shipping length: 25mm
- UPC: 814520014108

## Item details

Made in USA

# Table of Contents

- Startpage
- PUSH BUTTON QD SLING SWIVEL SAFETY INSTRUCTIONS
- About Us

# PUSH BUTTON QD SLING SWIVEL SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the Push Button QD Sling Swivel from Blue Force Gear. This product is designed to provide a secure and quiet attachment point for slings, allowing for quick removal and installation on various weapons. To ensure safe and effective use, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Always ensure that your weapon is equipped with a QD (Quick Detach) socket before attaching the sling swivel.
- Regularly inspect the sling swivel for any signs of wear or damage before each use.
- Keep the sling swivel clean and lubricated to ensure smooth operation.
- Store the sling swivel in a dry place when not in use to prevent corrosion.
- Be aware of your surroundings and handle the weapon safely at all times.

## Specific Safety Precautions for Use

- Ensure that the push button is functioning correctly before use. If it feels jammed or does not engage smoothly, do not use the swivel until it has been inspected.
- Do not overload the sling swivel beyond its intended use. Ensure that the sling and swivel are compatible with the weapon's weight and type.
- Avoid using the sling swivel in extreme conditions (e.g., heavy rain, extreme heat) unless it is specifically rated for such use.
- Use caution when attaching or detaching the sling swivel, especially in stressful situations or while wearing gloves.
- For attaching the swivel to railed forends without integral QD sockets, use the Rail Mounted Push Button Swivel Socket.

## Instructions for Installation and Usage

### 1. Attaching the Sling Swivel:

- Ensure your weapon has a QD socket.
- Align the sling swivel with the QD socket.
- Push the swivel into the socket until you hear a click, indicating it is securely attached.

### 2. Detaching the Sling Swivel:

- To detach, press the push button firmly while pulling the swivel out of the socket.
- Ensure the swivel is fully disengaged before storing or moving the weapon.

### 3. Maintenance:

- Every time you clean your weapon, place a small drop of oil or gun lube down the push button channel to ensure smooth operation and protect the internals from corrosion.
- Inspect the swivel for any dirt or debris that may hinder its function and clean it as necessary.

### 4. Choosing Loop Size:

- The 1" swivel can be used on any Vickers Sling that has 1.25" webbing and keeps the swivel more

stationary.

- The 1.25" swivel allows for more movement of the webbing and can also be used on any Vickers Sling.

## **Disposal Instructions**

- Dispose of the sling swivel in accordance with local regulations for metal and plastic waste.
- Do not dispose of the sling swivel in regular household waste if it is damaged or nonfunctional.

## **Contact Information for Further Support**

For any questions or concerns regarding the Push Button QD Sling Swivel, please contact the manufacturer directly. Ensure you have the product details handy for a quicker response.

By adhering to these safety instructions, you can ensure a safe and effective experience with your Push Button QD Sling Swivel. Always prioritize safety when handling firearms and their accessories.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)