

RUGER® 10/22® TRIGGER GUARD 2000 - VOLQUARTSEN TG2000 DROP-IN REPLACEMENT TRIGGER FOR RUGER 10/22 OD GREEN

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Machined Billet Housing Drops In For Precise, Consistent Trigger Pull

Completely new, CNC machined trigger housing with precision EDM trigger parts all pre-fitted and ready to drop-in, for a crisp, clean trigger pull.

Hardened EDM sear and disconnector have tolerances held to +/- .0002".

Hardened stainless steel hammer has notches surface ground to achieve the correct engagement angles, provides long-wearing performance. Reduced power hammer and sear springs lighten pull. Trigger includes overtravel adjustment. Hardened, polished trigger plunger is repositioned to depress directly to the rear as trigger is pulled; plunger spring is redesigned for better response. Oversized hammer, sear and action pins remove wobble that ruins a great action job. Includes auto bolt release and extended magazine release.

NO IMAGE
AVAILABLE

Attributes

- Name: [VOLQUARTSEN TG2000 DROP-IN REPLACEMENT TRIGGER FOR RUGER 10/22 OD GREEN](#)
- Manufacturer: [VOLQUARTSEN](#)
- Product no.: 430103497
- Mfr. No.: VCTP-1-OD-10
- Model: 10/22
- Style: Single-Stage
- Weapon type: Ruger
- Delivery weight: 0.204kg
- Shipping height: 36mm
- Shipping width: 86mm
- Shipping length: 145mm
- UPC: 810162013615

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for RUGER® 10/22® TRIGGER GUARD 2000 VOLQUARTSEN TG2000 DROPIN REPLACEMENT TRIGGER
- About Us

Safety Instruction Guide for RUGER® 10/22® TRIGGER GUARD 2000 VOLQUARTSEN TG2000 DROPIN REPLACEMENT TRIGGER

Introduction

Thank you for choosing the RUGER® 10/22® TRIGGER GUARD 2000 VOLQUARTSEN TG2000 DROPIN REPLACEMENT TRIGGER. This product is designed to enhance your shooting experience while ensuring safety and reliability. This guide provides important safety instructions and guidelines for the proper use and maintenance of your trigger. Please read this guide carefully to ensure safe operation.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure that the trigger is not pulled unless you are ready to fire.
- Keep your finger off the trigger until you are ready to shoot.
- Store firearms and ammunition in a secure location, out of reach of children and unauthorized users.
- Regularly check your firearm and trigger for any signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the trigger is installed correctly before using the firearm.
- Only use the trigger with compatible RUGER® 10/22® models.
- Do not modify the trigger or firearm in any way that could compromise safety.
- Use only recommended ammunition types for your firearm.
- Be aware of your surroundings and ensure that there are no people or animals in the line of fire.
- If you are unsure about the operation of your trigger or firearm, seek assistance from a qualified professional.

Instructions for Installation and Usage

Installation Instructions

1. **Safety First:** Ensure that your firearm is unloaded before beginning installation.
2. **Remove the Old Trigger:** Follow the manufacturer's instructions to safely remove the existing trigger guard and trigger components.
3. **Prepare the New Trigger:** Unpack the RUGER® 10/22® TRIGGER GUARD 2000 and inspect it for any visible defects.
4. **Install the New Trigger:**
 - Align the trigger housing with the firearm's receiver.
 - Insert the oversized hammer, sear, and action pins to secure the trigger in place.
 - Ensure that the trigger plunger is positioned correctly to allow for proper function.
5. **Adjust Overtravel:** Use the provided adjustment mechanism to set the desired amount of overtravel.
6. **Final Check:** Before closing the firearm, doublecheck that all components are securely in place and functioning correctly.

Usage Instructions

- Ensure that you are familiar with the operation of your firearm and the new trigger before firing.
- Conduct a function check to ensure that the trigger operates smoothly and safely.

- Always wear appropriate eye and ear protection when shooting.
- Maintain a safe distance from others while shooting.

Disposal Instructions

- Dispose of the trigger and any associated parts in accordance with local regulations.
- Do not dispose of the product in household waste.
- If the product is defective or no longer usable, contact the manufacturer for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the RUGER® 10/22® TRIGGER GUARD 2000 VOLQUARTSEN TG2000 DROPIN REPLACEMENT TRIGGER, please refer to the manufacturer's website or customer service for assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk