

X MODEL 360 BUCKHAMMER LEVER ACTION RIFLE - X MODEL 360 BUCKHAMMER 21.375" BBL 5 ROUND BLACK

[Firearms](#) > [Rifles](#) > [Lever Action](#)

While .360 Buckhammer may be the new kid on the block when it comes to straight wall cartridges, it comes in swinging for the fences with unrivaled performance and a point to prove. That sort of tenacity requires a platform that can keep up. Enter the Henry Lever Action X Model - a platform combining modern performance with classic lever action lineage. Developed in partnership with Remington Ammunition, .360 Buckhammer was created to rule the deer woods with a design optimized for lever action rifles, accuracy out to 200 yards and beyond, higher velocity, and less bullet drop than the competition. In short, it's the ultimate straight wall cartridge for today's whitetail woodsman, and there's no better companion than this feature-packed rifle. Tough synthetic furniture shaves off some weight compared to wood while providing worry-free durability when hunting gets rough and rugged. A Picatinny rail section at the bottom of the forearm is an excellent location for a bi-pod to steady your shots, and M-Lok accessory slots and inline swivel studs are yours to use as you see fit. The round blued steel barrel features a 1 in 12 twist to stabilize various bullet weights and 5/8x24 threading at the muzzle for a suppressor or other muzzle device.



Attributes

- Name: [X MODEL 360 BUCKHAMMER 21.375" BBL 5 ROUND BLACK](#)
- Manufacturer: [HENRY REPEATING ARMS](#)
- Product no.: 430105724
- Mfr. No.: H009X-360BH
- Action Type: Lever Action
- Barrel Length: 21.375"
- Capacity: 5-Round
- Cartridge: 360 Buckhammer
- Finish: Blued
- Front Sight: Fiber Optic
- Length: 40.375"
- Magazine Included: 1 x 5-Round
- Magazine Type: Tubular
- Make: Henry
- Model: X Model
- Muzzle: Non-Threaded
- Rear Sight: Adjustable
- Stock Material: Synthetic
- Weight: 8.07 lbs
- Delivery weight: 4.568kg
- Shipping height: 51mm
- Shipping width: 178mm
- Shipping length: 1,080mm
- UPC: 619835090256

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- Startpage
- Safety Instruction Guide for the X Model 360 Buckhammer Lever Action Rifle
- About Us

Safety Instruction Guide for the X Model 360 Buckhammer Lever Action Rifle

Introduction

Thank you for choosing the X Model 360 Buckhammer Lever Action Rifle. This guide provides essential safety instructions to ensure the safe and effective use of your firearm. It is vital to follow these guidelines to minimize risks and ensure a safe shooting experience.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Never place your finger on the trigger until you are ready to shoot.
- Ensure your target and what lies beyond it are safe before firing.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your rifle for any signs of wear or damage.
- Use only the recommended ammunition for your rifle.
- Be aware of your surroundings and the laws regarding firearm usage in your area.

Specific Safety Precautions for Use

• Firearm Handling:

- Always wear appropriate eye and ear protection when shooting.
- Do not consume alcohol or drugs before or during the use of the firearm.
- Ensure the safety is engaged until you are ready to fire.

• Shooting Environment:

- Choose a suitable shooting range or area that is designated for firearm use.
- Be cautious of other people and animals in the vicinity.

• Maintenance:

- Clean your rifle regularly to ensure it functions properly.
- Follow the manufacturer's instructions for cleaning and maintenance.

Instructions for Installation and Usage

• Installation of Accessories:

- If you are attaching a bipod or other accessories, ensure they are securely fastened to the Picatinny rail section.
- Use M Lok accessory slots for additional attachments as needed.

• Loading the Rifle:

- Ensure the rifle is pointed in a safe direction.
- Open the action and insert the magazine into the magazine well.
- Pull the lever to chamber a round.

• Firing the Rifle:

- Ensure your stance is stable and your grip is secure.
- Aim at your target and ensure it is safe to fire.
- When ready, disengage the safety and pull the trigger smoothly.

- **Unloading the Rifle:**

- Point the rifle in a safe direction.
- Open the action and remove the magazine.
- Pull the lever to eject any chambered round.

Disposal Instructions

- Dispose of the rifle according to local laws and regulations.
- Ensure that the firearm is rendered inoperable before disposal.
- Contact local authorities or firearm disposal services for proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance regarding the safety of your X Model 360 Buckhammer Lever Action Rifle, please refer to the contact information provided by the manufacturer or your local dealer.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your X Model 360 Buckhammer Lever Action Rifle. Always prioritize safety and responsible firearm ownership.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at