

RUGER® 10/22® MOE® X-22 RIFLE STOCK - RUGER 10/22 MOE HUNTER X-22 STOCK - BLACK

The MOE® X-22 Stock is the ideal rimfire stock for those looking for a lightweight, budget-friendly upgrade for their Ruger® 10/22®. Featuring M-LOK slots at the 6 o'clock position, as well as Magpul's own exclusive TSP texture on the pistol grip, the overall weight of the stock tips the scales at slightly more than a pound (19 oz.). The stock sports integral sling loops on the toe and fore end for use with locking sling swivels, and with the ergonomic nylon butt-pad, the stock has a length-of-pull measurement of 13.5". In short, the MOE X-22 Stock is built for lean efficiency. The MOE X-22 is available with two diameter barrel trays to support both factory pencil and bull-barrel profiles to provide shooters with options for various configurations. Lightweight at just over a pound at 19 oz. Ergonomic, non-slip, polymer butt-ad with angled toe TSP texture 2 M-LOK® slots at 6 o'clock Integral loops compatible with Uncle Mike's® sling swivels Interchangeable barrel trays for factory pencil and bull-barrel profiles Interchangeable barrel trays accept all factory barrels as well as aftermarket up to 0.920" diameter (12.5" minimum length) ensuring proper fit with pencil profile as well as heavy bull barrels Compatible with semi-auto and straight pull Ruger 10/22 style receivers. Same as Hunter® X-22 for receiver fitments. Factory pencil and bull-barrel profiles. Platform Ruger® 10/22 Compatibility Drop-in design compatible with factory Ruger 10/22 .22 LR receivers Butt-Pad Dimensions 1.5 x 4.5 in. Length 28.6 in. Length of Pull 13.5 in. Weight 18.9 oz.



Attributes

- Name: RUGER 10/22 MOE HUNTER X-22 STOCK - BLACK
- Manufacturer: MAGPUL
- Product no.: 430106905
- Mfr. No.: MAG1428-BLK
- Action Type: Rimfire
- Color: Black
- Make: Ruger
- Material: Polymer
- Model: 10/22
- Style: Fixed
- Weight: 1.181 lbs
- Delivery weight: 1.197kg
- UPC: 840815147572

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: RUGER® 10/22® MOE® X22 RIFLE STOCK SAFETY INSTRUCTIONS](#)
- [Suomi: RUGER® 10/22® MOE® X22 RIFLE STOCK Käyttöohjeet ja turvallisuusohjeet](#)

RUGER® 10/22® MOE® X22 RIFLE STOCK SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the RUGER® 10/22® MOE® X22 Rifle Stock. This product is designed to enhance your shooting experience while ensuring safety and compliance with the EU General Product Safety Regulation (GPSR). Please read this safety instruction guide carefully to understand how to use, install, and dispose of your rifle stock safely.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Always handle firearms with care and store them safely when not in use.
- Keep the rifle stock and all associated components out of reach of children and unauthorized users.
- Regularly check for any signs of wear or damage to the stock and its components.
- If you encounter any issues or malfunctions, cease use immediately and seek assistance.

Specific Safety Precautions for Use

- Ensure that the rifle stock is compatible with your Ruger® 10/22® model.
- Do not exceed the manufacturer's weight limits; the stock is designed for use with standard factory and aftermarket barrels up to 0.920" diameter.
- Always use locking sling swivels with the integral sling loops to prevent accidental detachment.
- Use the ergonomic buttpad correctly to avoid slips during use.
- Avoid using the rifle stock in adverse weather conditions that could affect your grip or the stock's integrity.

Instructions for Installation and Usage

1. Installation:

- Carefully remove the existing stock from your Ruger® 10/22® following the manufacturer's instructions.
- Align the MOE® X22 Stock with the receiver and ensure it fits securely.
- Attach the stock using the provided screws, ensuring they are tightened to the manufacturer's specifications.
- Install the barrel trays as needed for your specific barrel profile (factory pencil or bullbarrel).

2. Usage:

- When using the rifle, ensure that the stock is securely attached to the receiver.
- Maintain a proper stance and grip while aiming and firing to ensure stability.
- Regularly check the stock and its attachments during use to ensure everything remains secure.

Disposal Instructions

- Dispose of the rifle stock in accordance with local regulations regarding plastic and polymer materials.
- Do not incinerate the stock, as it may release harmful substances.
- If the stock is damaged beyond repair, contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, compatibility, or product performance, please refer to the manufacturer's website or customer service resources. Ensure you have the product details on hand when seeking assistance.

By following these guidelines, you can help ensure a safe and enjoyable experience with your RUGER® 10/22® MOE® X22 Rifle Stock. Thank you for your attention to safety and compliance.

RUGER® 10/22® MOE® X22 RIFLE STOCK

Käyttöohjeet ja turvallisuusohjeet

Johdanto

Tervetuloa RUGER® 10/22® MOE® X22 RIFLE STOCK tuotteen käyttöohjeisiin. Tämä opas tarjoaa tärkeitä tietoja tuotteen turvallisesta käytöstä, asennuksesta ja hävittämisestä. Lue tämä opas huolellisesti ennen tuotteen käyttöä varmistaaksesi turvallisen ja tehokkaan käyttökokemuksen.

Yleiset turvallisuusohjeet

- Varmista, että tuote on asennettu oikein ennen käyttöä.
- Tarkista tuote säännöllisesti vaurioiden tai kulumisen varalta.
- Älä käytä tuotetta, jos se on vaurioitunut tai siinä on puutteita.
- Säilytä tuote lasten ulottumattomissa.
- Käytä tuotetta vain siihen tarkoitetuilla aseilla.
- Noudata kaikkia valmistajan antamia ohjeita ja suosituksia.

Erityiset turvallisuustoimenpiteet käytössä

- Varmista, että ase on tyhjennetty ja turvallinen ennen tuotteen asentamista tai poistamista.
- Käytä aina suojaruukkeita, kuten suojalaseja ja kuulosuojaimia, ampumisen aikana.
- Vältä tuotteen käyttöä kosteissa tai märissä olosuhteissa.
- Älä muokkaa tai yritä korjata tuotetta itse; ota yhteys asiantuntevaan huoltoon, jos ongelmia ilmenee.
- Käytä tuotetta vain valmistajan hyväksymien lisävarusteiden kanssa.

Asennus ja käyttöohjeet

1. Asennus

- Varmista, että ase on tyhjennetty.
- Poista vanha kanta, jos sellainen on käytössä.
- Aseta MOE® X22 kanta aseeseen ja varmista, että se on kunnolla paikallaan.
- Kiinnitä kanta valmistajan ohjeiden mukaisesti.
- Tarkista, että kaikki kiinnitykset ovat tiukkoja ja turvallisia.

2. Käyttö

- Kun kanta on asennettu, tarkista sen toiminta ennen ampumista.
- Varmista, että kaikki osat liikkuvat sujuvasti.
- Käytä tuotetta vain valmistajan määrittämällä tavalla.

Hävittämisohjeet

- Hävitä tuote paikallisten jätteiden käsittelyohjeiden mukaisesti.
- Älä heitä tuotetta tavalliseen sekajätteeseen.
- Kierrätä mahdolliset muoviosat, jos mahdollista.

Lisätietoja ja tuki

Jos tarvitset lisätietoja tai tukea, ota yhteys valmistajaan tai tarkista heidän verkkosivustonsa. Varmista, että sinulla on mukana kaikki tarvittavat tiedot, kuten tuotteen malli ja sarjanumero.

Huomautus

Tämä tuote on suunniteltu noudattamaan EU:n yleistä tuotesääntelyä (GPSR). Varmista, että noudatat kaikkia paikallisia lakeja ja määräyksiä tuotteen käytön aikana. Ilmoita mahdollisista vaarallisista tuotteista tai onnettomuuksista asianomaisille viranomaisille. Tarkista myös EU:n Safety Gate alustalta mahdolliset tuotteen takaisinvetotiedot.

Kiitos, että valitsit RUGER® 10/22® MOE® X22 RIFLE STOCK tuotteen!