

LEVER STOCK SPACER PLATE - MIDWEST INDUSTRIES LEVER STOCK SPACER PLATE

[Rifle Parts](#) > [Stock Parts](#) > [Buttstocks](#)

Extends the length of pull for MI Lever Gun Stocks. Adds .5" to length of pull
Made in the USA Only compatible with MI Lever Stock



Attributes

- Name: [MIDWEST INDUSTRIES LEVER STOCK SPACER PLATE](#)
- Manufacturer: [MIDWEST INDUSTRIES](#)
- Product no.: 430107674
- Mfr. No.: MI-LS-SP
- Colour: Black
- Material: Aluminum
- Delivery weight: 0.454kg
- Shipping height: 23mm
- Shipping width: 44mm
- Shipping length: 140mm
- UPC: 812102034476

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for LEVER STOCK SPACER PLATE
- About Us

Safety Instruction Guide for LEVER STOCK SPACER PLATE

Introduction

Thank you for choosing the LEVER STOCK SPACER PLATE by Midwest Industries. This product is designed to extend the length of pull for MI Lever Gun Stocks by adding 0.5 inches. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Always handle the product with care to avoid injury.
- Ensure the product is compatible with your specific MI Lever Gun Stock.
- Regularly check for any signs of wear or damage before installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the product is installed correctly to avoid any malfunction.
- Do not exceed the recommended weight limits of your MI Lever Gun Stock.
- Avoid using the product in extreme weather conditions that may affect its integrity.
- Follow all manufacturer guidelines and recommendations for safe use.
- If you experience any issues while using the product, cease use immediately and consult a professional.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools for installation (e.g., screwdriver, wrench).
- Ensure that your workspace is clean and free of distractions.

2. Installation Steps

- Remove the existing stock from your MI Lever Gun.
- Align the LEVER STOCK SPACER PLATE with the stock mounting points.
- Secure the spacer plate using the provided screws, ensuring a tight fit.
- Reattach the stock to the firearm, ensuring all components are properly aligned.
- Check for stability and secure all fastenings before use.

3. Usage

- Adjust your grip and stance according to the extended length of pull.
- Regularly inspect the spacer plate and stock for any signs of instability or wear.
- If the product becomes loose during use, stop immediately and recheck the installation.

Disposal Instructions

- Dispose of the LEVER STOCK SPACER PLATE in accordance with local regulations.
- Do not dispose of the product in general waste.
- Consider recycling if possible to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding the LEVER STOCK SPACER PLATE, please refer to the manufacturer's website or your point of purchase for contact details and support resources.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we hope you enjoy using the LEVER STOCK SPACER PLATE.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk