

# **L5AWM GEN 2 5.56x45 NATO RIFLE MAGAZINE - LANCER SYSTEMS**

## **L5AWM GEN2 5.56X45 NATO 20RD MAGAZINE FLAT DARK EARTH**

[Magazines](#) > [Rifle Magazines](#) > [Magazines](#)

Lancer set out to design a better 5.56 magazine, one with the reliability of steel and the durability and weight of polymer. The L5 Advanced Warfighter Magazine (AWM®) is that magazine. The GEN 2 features an all-new precision engineered feed lip design, stainless steel spring, anti-tilt follower and new floorplate lock, the new L5AWM GEN 2 is positioned to secure its place as the leading professional grade "STANAG style" magazine on the market. The L5AWM's exclusive hybrid design includes a proprietary polymer body with aggressive surface texturing to create the ultimate rifle magazine tough enough for military, law enforcement, and competition applications. The L5AWM is compatible with modern weapon systems, including M4/M16/AR15, SCAR16, HK416, ARX160, SIG556, ARC, SIG MCX, IWI Tavor, IWI X95, SA80, chambered in 5.56x45mm / .223 Remington. Designed, tooled, manufactured, and assembled in the USA!



### **Attributes**

- Name: [LANCER SYSTEMS L5AWM GEN2 5.56X45 NATO 20RD MAGAZINE FLAT DARK EARTH](#)
- Manufacturer: [LANCER SYSTEMS](#)
- Product no.: 430108891
- Mfr. No.: L5-G2-20-FDE
- Capacity: 20-Round
- Cartridge: 5.56 mm NATO
- Finish: Flat Dark Earth
- Material: Polymer
- Weapon type: AR-15
- Delivery weight: 0.095kg
- UPC: 738435622268

### **Item details**

Made in USA

US export classification: 0A501.d

# Table of Contents

- Startpage
- L5AWM GEN 2 5.56x45 NATO Rifle Magazine Safety Instructions
- About Us

# **L5AWM GEN 2 5.56x45 NATO Rifle Magazine Safety Instructions**

## **Introduction**

Thank you for choosing the L5AWM GEN 2 5.56x45 NATO Rifle Magazine by Lancer Systems. This safety instruction guide provides essential information to ensure the safe use, installation, and disposal of your magazine. Please read this guide carefully to understand the safety precautions and how to properly handle the magazine.

## **General Safety Guidelines**

To ensure safe use of the L5AWM GEN 2 magazine, please follow these general safety guidelines:

- Always handle the magazine with care, treating it as if it is loaded.
- Keep the magazine out of reach of children and unauthorized persons.
- Use only compatible firearms (M4/M16/AR15, SCAR16, HK416, ARX160, SIG556, ARC, SIG MCX, IWI Tavor, IWI X95, SA80) chambered in 5.56x45mm or .223 Remington.
- Inspect the magazine regularly for signs of damage or wear. Do not use a damaged magazine.
- Store the magazine in a cool, dry place away from direct sunlight and extreme temperatures.
- Always follow the manufacturer's instructions for your firearm when using this magazine.

## **Specific Safety Precautions for Use**

When using the L5AWM GEN 2 magazine, it is important to observe the following specific safety precautions:

- Ensure the firearm is in a safe condition before inserting or removing the magazine.
- Do not exceed the magazine's capacity of 20 rounds.
- Avoid using reloaded or handloaded ammunition unless it has been verified for safety and compatibility.
- Never attempt to modify or disassemble the magazine. Doing so may compromise its integrity and safety.
- If the magazine fails to feed properly, cease use immediately and inspect for obstructions or damage.
- Always keep the firearm pointed in a safe direction when loading or unloading the magazine.

## **Instructions for Installation and Usage**

Follow these steps for the proper installation and usage of the L5AWM GEN 2 magazine:

### **1. Installation:**

- Ensure the firearm is unloaded and pointed in a safe direction.
- Align the magazine with the magazine well of the firearm.
- Push the magazine firmly into place until you hear a click, indicating it is securely locked.

### **2. Loading the Magazine:**

- Place the magazine on a stable surface.
- Use your thumb to press down on the follower while inserting rounds from the rear of the magazine.
- Load a maximum of 20 rounds to avoid overloading.

### **3. Removing the Magazine:**

- Ensure the firearm is pointed in a safe direction.

- Press the magazine release button on the firearm.
- Grasp the magazine and pull it out of the magazine well.

#### **4. Unloading the Magazine:**

- Remove the magazine from the firearm.
- Press the follower down and remove each round carefully.
- Inspect the magazine for any damage before storing.

## **Disposal Instructions**

When it comes time to dispose of the L5AWM GEN 2 magazine, please follow these disposal instructions:

- If the magazine is damaged or no longer functional, do not attempt to repair it.
- Check local regulations for the disposal of firearm accessories.
- Dispose of the magazine in accordance with local waste management guidelines.
- If possible, recycle the magazine as it is made from polymer material.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the L5AWM GEN 2 magazine, please refer to the manufacturer's website or customer support channels. Ensure you have your product details ready for assistance.

## **Conclusion**

Your safety is our priority. By following these guidelines, you can ensure the safe use of your L5AWM GEN 2 5.56x45 NATO Rifle Magazine. Always prioritize safety and compliance with local laws and regulations. Thank you for your attention to these important safety instructions.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)