

ERGO ROLLER LEVER FOR RELOADING PRESSES - ERGO ROLLER LEVER FOR LEE BREECHLOCK CHALLNGR SGL STGE PRESS

Inline Fabrication manufactures several accessories to enhance your reloading experience. Each Ergo Roller lever is made specifically for a specific model of press to position you in the most ergonomic reloading position. The forward offset design of the ergonomic levers snug you into your press, positions you perfectly to see your powder charge before placing a bullet, keeps you from bending/leaning over time after time and keeps you comfortable through-out your reloading session. The roller handle is super smooth and a dream to use. The levers are lathe cut & threaded; then black powder coated. The roller bearing handle is very comfortable diameter to grip and a dream to use.



Attributes

- Name: ERGO ROLLER LEVER FOR LEE BREECHLOCK CHALLNGR SGL STGE PRESS
- Manufacturer: INLINE FABRICATION
- Product no.: 430112036
- Mfr. No.: LEL5
- Delivery weight: 1.247kg
- Shipping height: 102mm
- Shipping width: 152mm
- Shipping length: 457mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: ERGO ROLLER LEVER FOR RELOADING PRESSES Safety Instruction Guide](#)

ERGO ROLLER LEVER FOR RELOADING PRESSES

Safety Instruction Guide

Introduction

Thank you for choosing the ERGO Roller Lever for Reloading Presses. This guide provides important safety instructions to ensure the safe and effective use of your reloading press accessory. Please read this manual carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this manual.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for wear and tear. Do not use if damaged.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the reloading press.
- Ensure that the work area is clean and free of obstructions to prevent accidents.
- Do not exceed the manufacturer's recommended load limits for your reloading press.
- Avoid distractions while using the reloading press to maintain focus and safety.
- Do not attempt to modify the ERGO Roller Lever or any associated equipment.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure that your reloading press is turned off and unplugged before installation.
2. **Positioning:** Align the ERGO Roller Lever with the designated mounting point on your reloading press.
3. **Securing:** Use the provided screws to secure the lever in place. Ensure it is tightly fitted to avoid any movement during use.
4. **Final Check:** Once installed, check that the lever moves smoothly and does not obstruct any other parts of the press.

Usage

1. **Starting Up:** Before starting, ensure that all components are securely installed and that the workspace is clear.
2. **Operation:** Use the roller handle to operate the press smoothly. Maintain a firm grip and avoid excessive force.
3. **Observation:** Always check the powder charge before placing a bullet to prevent overcharging.
4. **PostUse:** After reloading, clean the area and the equipment to maintain optimal performance.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- When the product reaches the end of its life, dispose of it responsibly. Check with local waste management authorities for proper disposal methods for metal and plastic materials.

Contact Information for Further Support

For inquiries regarding safety or product issues, please contact the manufacturer directly through their official channels. Ensure to have your product details ready for reference.

Thank you for prioritizing safety while using the ERGO Roller Lever for Reloading Presses. Your adherence to these guidelines helps ensure a safe and enjoyable reloading experience.