

# UNIVERSAL SHELL HOLDERS - UNIVERSAL SHELL HOLDER FN 5.7X28 #15

Universal shell holder used in most brands of reloading presses. Will not work with Lee Auto Prime. View Lee Shellholder Chart



## Attributes

- Name: UNIVERSAL SHELL HOLDER FN 5.7X28 #15
- Manufacturer: LEE PRECISION
- Product no.: 430113033
- Mfr. No.: 92183
- Cartridge: 5.7 x 28 mm
- Style: -
- Delivery weight: 0.022kg
- Shipping height: 15mm
- Shipping width: 97mm
- Shipping length: 127mm
- UPC: 734307921835

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for UNIVERSAL SHELL HOLDER FN 5.7X28 #15](#)

# Safety Instruction Guide for UNIVERSAL SHELL HOLDER FN 5.7X28 #15

## Introduction

Thank you for choosing the UNIVERSAL SHELL HOLDER FN 5.7X28 #15. This product is designed to be used with most brands of reloading presses, providing a reliable solution for your reloading needs. However, it is crucial to follow safety guidelines to ensure safe and effective usage.

## General Safety Guidelines

- Always read and understand the product instructions before use.
- Ensure that the shell holder is compatible with your reloading press model.
- Keep the shell holder out of reach of children and vulnerable individuals.
- Regularly inspect the shell holder for wear or damage before each use.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Do not use the shell holder with Lee Auto Prime, as it is incompatible.
- Ensure that the reloading press is stable and secure before use.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when reloading.
- Follow all manufacturer guidelines for the reloading process.
- Avoid overtightening the shell holder to prevent damage to both the holder and the reloading press.
- Be aware of the potential hazards associated with handling reloading materials, including lead exposure.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the reloading press is powered off and unplugged.
- Locate the shell holder slot on your reloading press.
- Align the UNIVERSAL SHELL HOLDER FN 5.7X28 #15 with the slot.
- Gently insert the shell holder into the slot until it fits securely.
- Verify that the shell holder is properly seated before proceeding.

### 2. Usage:

- Load the appropriate cartridge (5.7 x 28 mm) into the shell holder.
- Ensure that the cartridge is seated correctly and securely.
- Follow the reloading press instructions for operating the equipment.
- Monitor the reloading process closely to ensure safety and effectiveness.
- After use, remove the shell holder from the press and clean it as needed.

## Disposal Instructions

- Dispose of the shell holder in accordance with local regulations.
- Do not dispose of the shell holder in regular household waste if it is damaged or worn.
- Check with local authorities for proper disposal methods for reloading equipment.

## Contact Information for Further Support

For any safety inquiries or further assistance regarding the UNIVERSAL SHELL HOLDER FN 5.7X28 #15, please refer to the manufacturer's contact information provided with the product.

Thank you for your attention to these safety guidelines. By following these instructions, you can ensure a safe and effective reloading experience.

