CANVAS SHOTGUN CASE 48" GREEN

BOB ALLEN CANVAS SHOTGUN CASE The Bob Allen Canvas Series Cases is built from a rugged canvas duck exterior with a top grain leather trim. The harness leather sling is designed for over the shoulder or hand carry. A leather tip is added for extra protection at the muzzle end of the case. A quilted flannel lined interior with thick cotton batting provides a soft bed for your firearm. A self-repairing nylon zipper and a 10"x4.5" accessory pocket add the final touches. FEATURES: Heavy-duty, water-resistant canvas duck exterior Quilted flannel lining with cotton batting Leather spine & sling Leather tip for added protection at the muzzle #10 Self-repairing nylon zipper track Lockable, double antique brass zippers w/leather zipper pulls 10"x4.5" exterior accessory pocket



Attributes

Name: CANVAS SHOTGUN CASE 48" GREEN

Manufacturer: BOB ALLENProduct no.: 430113046

Mfr. No.: 14534Color: GreenMaterial: Canvas

• Size: 48

Style: Shotgun

Delivery weight: 1.089kg
Shipping height: 38mm
Shipping width: 229mm
Shipping length: 1,346mm
UPC: 617867117125

Table of Contents

- StartpageEnglish: Safety Instructions for Bob Allen Canvas Shotgun Case

Safety Instructions for Bob Allen Canvas Shotgun Case

Introduction

Thank you for choosing the Bob Allen Canvas Shotgun Case. This product is designed to provide safe and secure storage for your shotgun. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the shotgun case is suitable for your firearm's size and type.
- Always inspect the case for any damage before use. Do not use if damaged.
- Keep the case out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding firearm storage and transportation.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Hazard Identification:
 - Risk of accidental discharge if firearms are improperly stored.
 - Risk of damage to the firearm if the case is not used correctly.

Avoiding Hazards:

- Always ensure the firearm is unloaded before placing it in the case.
- Use the leather tip of the case to protect the muzzle from damage.
- Ensure the zipper is fully closed before transporting the case.
- Do not overload the accessory pocket; it is designed for small items only.

AgeSpecific Warnings:

 This product is not intended for use by children. Always supervise children around firearms and firearm storage.

Instructions for Installation and Usage

- Installation:
 - No installation is required. The case is ready for use upon purchase.
- Usage:
 - Open the case using the selfrepairing nylon zipper.
 - Carefully place the unloaded shotgun into the case, ensuring it is positioned correctly.
 - Close the case securely, ensuring the zipper is fully engaged.
 - Use the leather sling for carrying over the shoulder or by hand.
 - Store the case in a cool, dry place away from direct sunlight when not in use.

Disposal Instructions

- Dispose of the shotgun case in accordance with local waste disposal regulations.
- If the case is damaged beyond use, consider recycling the materials where possible.
- Do not burn the case, as it may release harmful substances.

Contact Information for Further Support

For any safety inquiries or to report unsafe products, please contact your local EU consumer safety authority.