

# CANVAS SHOTGUN CASE 52" GREEN

BOB ALLEN CANVAS SHOTGUN CASE The Bob Allen Canvas Series Cases is built from a rugged canvas duck exterior with a top grain leather trim. The harness leather sling is designed for over the shoulder or hand carry. A leather tip is added for extra protection at the muzzle end of the case. A quilted flannel lined interior with thick cotton batting provides a soft bed for your firearm. A self-repairing nylon zipper and a 10"x4.5" accessory pocket add the final touches. FEATURES: Heavy-duty, water-resistant canvas duck exterior Quilted flannel lining with cotton batting Leather spine & sling Leather tip for added protection at the muzzle #10 Self-repairing nylon zipper track Lockable, double antique brass zippers w/leather zipper pulls 10"x4.5" exterior accessory pocket



## Attributes

- Name: CANVAS SHOTGUN CASE 52" GREEN
- Manufacturer: BOB ALLEN
- Product no.: 430113047
- Mfr. No.: 14535
- Color: Green
- Material: Canvas
- Size: 52
- Style: Shotgun
- Delivery weight: 1.089kg
- Shipping height: 38mm
- Shipping width: 229mm
- Shipping length: 1,346mm
- UPC: 617867117132

# Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Bob Allen Canvas Shotgun Case](#)

# Safety Instruction Guide for Bob Allen Canvas Shotgun Case

## Introduction

Thank you for choosing the Bob Allen Canvas Shotgun Case. This guide provides essential safety instructions to ensure the proper use and maintenance of your shotgun case. Please read this document carefully to understand how to protect yourself and others while using this product.

## General Safety Guidelines

- Ensure the shotgun case is used exclusively for its intended purpose: to store and transport shotguns safely.
- Always check the condition of the case before use. Do not use if it is damaged or shows signs of wear.
- Keep the case away from heat sources, sharp objects, and excessive moisture to maintain its integrity.
- Store the case in a cool, dry place when not in use.
- Always supervise children when the case is present to prevent accidents.

## Specific Safety Precautions for Use

- When carrying the shotgun case, ensure that the firearm is unloaded and secured inside the case.
- Use the leather sling for overtheshoulder carry or hand carry to keep your hands free for better control.
- Do not overload the accessory pocket beyond its intended capacity (10"x4.5").
- Avoid placing heavy objects on top of the case to prevent damage.

## Instructions for Installation and Usage

1. **Unpacking:** Carefully remove the shotgun case from its packaging. Inspect for any damage or missing components.
2. **Loading the Shotgun:**
  - Ensure the shotgun is unloaded.
  - Open the case using the selfrepairing nylon zipper.
  - Place the shotgun inside the case, muzzle end first, ensuring it is positioned securely.
  - Close the case and ensure the zipper is fully engaged.
3. **Using the Sling:**
  - Adjust the harness leather sling to your preferred length.
  - Securely position the sling over your shoulder or grip the case by hand.
4. **Transporting the Case:**
  - Always keep the case upright during transport to prevent any shifting of contents.
  - Avoid exposing the case to extreme weather conditions for prolonged periods.
5. **Maintenance:**
  - Wipe the exterior with a damp cloth to remove dirt and debris.
  - Allow the case to air dry completely before storing it.

## Disposal Instructions

- When the shotgun case reaches the end of its life cycle, dispose of it in accordance with local waste management regulations.
- Recycle materials where possible, such as canvas and leather, to minimize environmental impact.

## Contact Information for Further Support

For any safety inquiries or product support, please refer to the manufacturer's contact information provided with your product packaging. Ensure you have the product details ready for any assistance.

Thank you for prioritizing safety while using your Bob Allen Canvas Shotgun Case. By following these guidelines, you can ensure a safe and enjoyable experience.