FULL MESH DUAL PAD SHOOTING VEST RED L

BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST FEATURES: Mesh construction reduces weight and increases ventilation Dual pads for left or right-handed shooters Side tab adjustment Includes interior pocket for Insert-A-Pad compatibility Bellowed front shell box pockets Rear mesh hull pouch Embroidery ready Available Colors: Khaki, Sage, Navy, Black, Red, Orange



Attributes

Name: FULL MESH DUAL PAD SHOOTING VEST RED L

Manufacturer: BOB ALLENProduct no.: 430113095Mfr. No.: 21489

Mfr. No.: 214Color: RedSize: Large

Delivery weight: 0.454kg
Shipping height: 6mm
Shipping width: 387mm
Shipping length: 572mm
UPC: 617867123003

Table of Contents

- StartpageEnglish: FULL MESH DUAL PAD SHOOTING VEST SAFETY INSTRUCTIONS

FULL MESH DUAL PAD SHOOTING VEST SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST. This guide provides essential safety instructions to ensure your safe use of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide thoroughly before using the vest.

General Safety Guidelines

- Ensure that the vest is suitable for your size and body type before use.
- Regularly inspect the vest for any signs of wear, damage, or loose parts.
- Always use the vest in accordance with its intended purpose.
- Keep the vest away from sharp objects, heat sources, and excessive moisture.
- Store the vest in a cool, dry place when not in use.
- If the vest is involved in an accident or shows signs of damage, discontinue use immediately and seek advice.

Specific Safety Precautions for Use

- The vest is designed for adult users. It is not suitable for children.
- Ensure that the vest is properly adjusted for a secure fit before engaging in shooting activities.
- Be aware of your surroundings and ensure that no one is in the line of fire when using the vest.
- Use the vest in conjunction with appropriate shooting safety equipment, such as ear and eye protection.
- If you experience discomfort or restricted movement while wearing the vest, remove it immediately.

Instructions for Installation and Usage

1. Adjusting the Vest:

- Locate the side tab adjustment straps.
- Adjust the straps until the vest fits snugly but comfortably around your body.
- Ensure that the dual pads are positioned correctly for your shooting preference (left or righthanded).

2. Using the InsertAPad Compatibility:

- Open the interior pocket designed for InsertAPad compatibility.
- Insert the pad as per the manufacturer's instructions.
- Secure the pocket to ensure that the pad remains in place during use.

3. Using the Front Shell Box Pockets:

- Utilize the bellowed front shell box pockets to store ammunition or other shooting accessories.
- Ensure that the pockets are closed securely when not in use to prevent items from falling out.

4. Using the Rear Mesh Hull Pouch:

- The rear mesh hull pouch is designed for easy access to spent shells.
- Ensure that the pouch is emptied regularly to maintain comfort and prevent obstruction.

Disposal Instructions

- When the vest reaches the end of its life cycle, dispose of it in accordance with local regulations.
- If the vest is damaged beyond repair, consider recycling materials where possible.
- Do not dispose of the vest in regular household waste if it contains any hazardous materials.

Contact Information for Further Support

For any inquiries regarding the safety and use of this product, please refer to the contact details provided on the packaging or the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure a safer experience while using the BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST. Stay safe and enjoy your shooting activities responsibly.