

# FULL MESH DUAL PAD SHOOTING VEST KHAKI 3XL

BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST FEATURES: Mesh construction reduces weight and increases ventilation Dual pads for left or right-handed shooters Side tab adjustment Includes interior pocket for Insert-A-Pad compatibility Bellowed front shell box pockets Rear mesh hull pouch Embroidery ready Available Colors: Khaki, Sage, Navy, Black, Red, Orange



## Attributes

- Name: FULL MESH DUAL PAD SHOOTING VEST KHAKI 3XL
- Manufacturer: BOB ALLEN
- Product no.: 430113111
- Mfr. No.: 21454
- Color: Khaki
- Size: 3X Large
- Delivery weight: 0.454kg
- Shipping height: 6mm
- Shipping width: 387mm
- Shipping length: 572mm
- UPC: 617867122792

# Table of Contents

- [Startpage](#)
- [English: FULL MESH DUAL PAD SHOOTING VEST Safety Instructions](#)

# FULL MESH DUAL PAD SHOOTING VEST Safety Instructions

## Introduction

Thank you for choosing the BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST. This product is designed to enhance your shooting experience while ensuring safety and comfort. Please read this safety instruction guide carefully to understand how to use and maintain your vest safely.

## General Safety Guidelines

- Ensure that the vest is appropriate for your body size and type before use. The vest is available in various sizes, including 3X Large.
- Always inspect the vest for any signs of damage or wear before each use. Do not use if the vest is damaged.
- Keep the vest away from fire and extreme heat sources to prevent material degradation.
- Store the vest in a cool, dry place when not in use to maintain its condition.
- Follow all local laws and regulations regarding the use of shooting apparel.

## Specific Safety Precautions for Use

- The vest is designed for left or righthanded shooters. Ensure that you adjust the dual pads accordingly for optimal comfort and safety.
- Use the side tab adjustment to achieve a secure fit. A properly fitted vest reduces the risk of accidents during use.
- The interior pocket is compatible with InsertAPad accessories. Ensure that any inserts used are properly secured.
- Be aware of your surroundings while wearing the vest, especially in shooting environments. Maintain a safe distance from others.
- If you notice any discomfort while wearing the vest, remove it immediately and check for proper fit and adjustment.

## Instructions for Installation and Usage

### 1. Fitting the Vest:

- Unbuckle the side tab adjustments.
- Slip the vest over your shoulders and adjust the straps to fit snugly but comfortably around your torso.
- Ensure the dual pads are positioned correctly for your shooting hand.

### 2. Using the Interior Pocket:

- Open the interior pocket by unfastening the closure.
- Insert the InsertAPad accessory if desired, ensuring it fits securely.
- Close the pocket to prevent the insert from moving during use.

### 3. Utilizing the Front Shell Box Pockets:

- The bellowed front shell box pockets can be used for storing ammunition or other small items.
- Ensure that items stored in the pockets are secure and do not impede your movement.

### 4. Maintaining the Vest:

- After each use, inspect the vest for any dirt or debris. Clean with a damp cloth if necessary.
- Do not machine wash or tumble dry. Allow the vest to air dry completely before storing.

## Disposal Instructions

- When the vest reaches the end of its life cycle, dispose of it responsibly.
- Check local regulations for guidance on textile disposal.
- Consider donating the vest if it is still in usable condition.

## **Contact Information for Further Support**

For any questions or safety inquiries regarding the BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST, please reach out to the designated EU contact point for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your BOB ALLEN FULL MESH DUAL PAD SHOOTING VEST. Thank you for your attention to safety.