

CLASSIC SERIES COMBO SHELL POUCH WITH BELT GREEN

BOB ALLEN CLASSIC SERIES COMBO SHELL POUCH WITH BELT

FEATURES: Durable, Water Resistant Nylon Construction Dual Shotgun Shell Box Compartments Mesh, Zippered Bottom Holds 100 Empty Shell Hulls Heavy-duty 2" Adjustable Web Belt Web Belt Adjustable from 26"-50" Size: 8" x 4" x 7"



Attributes

- Name: CLASSIC SERIES COMBO SHELL POUCH WITH BELT GREEN
- Manufacturer: BOB ALLEN
- Product no.: 430113154
- Mfr. No.: 20167
- Color: Green
- Material: Nylon
- UPC: 019691201672

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for CLASSIC SERIES COMBO SHELL POUCH WITH BELT](#)

Safety Instruction Guide for CLASSIC SERIES COMBO SHELL POUCH WITH BELT

Introduction

Thank you for choosing the BOB ALLEN CLASSIC SERIES COMBO SHELL POUCH WITH BELT. This product is designed to provide you with a durable and practical solution for carrying shotgun shells. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Regularly inspect the pouch and belt for any signs of wear or damage.
- Keep the pouch out of reach of children when not in use.
- Avoid exposure to extreme temperatures and harsh chemicals that may degrade the material.
- In case of any malfunction or damage, discontinue use immediately.

Specific Safety Precautions for Use

- Do not overload the pouch beyond its capacity (100 empty shell hulls).
- Ensure that the belt is securely fastened before use to prevent accidental dropping of the pouch.
- When adjusting the belt size, ensure it fits snugly but comfortably to avoid slipping during use.
- Be cautious when using the zipper to avoid pinching fingers or catching on clothing.
- Store the pouch in a cool, dry place when not in use to maintain its condition.

Instructions for Installation and Usage

1. Adjusting the Belt:

- Unbuckle the belt.
- Pull the webbing to adjust the size from 26" to 50".
- Buckle the belt securely once adjusted to the desired size.

2. Loading the Pouch:

- Open the zippered bottom of the pouch.
- Insert up to 100 empty shell hulls into the designated compartments.
- Ensure that the shells are placed securely to avoid shifting during transport.

3. Wearing the Pouch:

- Place the belt around your waist.
- Position the pouch on your side for easy access.
- Fasten the belt securely to ensure stability while moving.

4. Cleaning and Maintenance:

- Wipe the exterior with a damp cloth to remove dirt and debris.
- Do not machine wash or tumble dry the pouch, as this may damage the material.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding textile waste.
- If the product is damaged beyond repair, consider recycling the materials where possible.
- Do not dispose of the pouch in regular household waste if it contains any hazardous materials.

Contact Information for Further Support

For any safety inquiries or concerns regarding the BOB ALLEN CLASSIC SERIES COMBO SHELL POUCH WITH BELT, please contact the appropriate consumer safety authority in your region.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your CLASSIC SERIES COMBO SHELL POUCH WITH BELT. Thank you for your attention to these important safety measures.