

SIGNATURE SERIES HANDICAP COMBO SHELL POUCH GREEN

BOB ALLEN SIGNATURE SERIES HANDICAP COMBO SHELL POUCH
FEATURES: Durable, Light-Weight Ripstop Nylon & Mesh Construction Holds
One Shotgun Shell Box in the Top Compartment Spring-Open Bottom Mesh
Compartment Holds 100 Empty Shell Hulls Back-Side Metal Clip for Belt
Attachment



Attributes

- Name: SIGNATURE SERIES HANDICAP COMBO SHELL POUCH GREEN
- Manufacturer: BOB ALLEN
- Product no.: 430113157
- Mfr. No.: 22126
- Color: Green
- Material: Nylon
- UPC: 617867115282

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for SIGNATURE SERIES HANDICAP COMBO SHELL POUCH](#)

Safety Instruction Guide for SIGNATURE SERIES HANDICAP COMBO SHELL POUCH

Introduction

Thank you for choosing the BOB ALLEN SIGNATURE SERIES HANDICAP COMBO SHELL POUCH. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this manual carefully before using the pouch to maximize your safety and enjoyment.

General Safety Guidelines

- Ensure safe use of the pouch by following all instructions provided in this manual.
- Regularly inspect the pouch for any signs of wear or damage before each use.
- Keep the pouch out of reach of children to prevent accidental use or injury.
- Use the pouch only for its intended purpose as described in this manual.
- In case of any safety concerns, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Do not overload the pouch beyond its intended capacity to avoid damage.
- When using the backside metal clip for belt attachment, ensure it is securely fastened to prevent accidental detachment.
- Avoid exposing the pouch to extreme temperatures or harsh chemicals that may degrade the materials.
- Always store the pouch in a dry place to prevent mold or mildew growth.

Instructions for Installation and Usage

1. Attaching the Pouch

- Locate the backside metal clip.
- Slide the clip onto your belt or waistband, ensuring it is securely attached.
- Adjust the position of the pouch for comfort and accessibility.

2. Using the Top Compartment

- Open the top compartment zipper.
- Place one shotgun shell box inside the compartment.
- Ensure the box is securely positioned to prevent movement during use.

3. Using the Bottom Mesh Compartment

- Open the springopen bottom mesh compartment.
- Load up to 100 empty shell hulls into the compartment.
- Close the compartment securely to avoid spillage during transport.

4. Maintenance

- Clean the pouch regularly with a damp cloth to remove dirt and debris.
- Allow the pouch to air dry completely before storing.
- Store the pouch in a cool, dry place when not in use.

Disposal Instructions

- When the pouch reaches the end of its life cycle, dispose of it responsibly.
- Check local regulations for proper disposal methods for nylon and mesh materials.
- Consider recycling the materials if possible to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the safety or usage of the SIGNATURE SERIES HANDICAP COMBO SHELL POUCH, please consult the appropriate authorities or your retailer.

By adhering to these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your BOB ALLEN SIGNATURE SERIES HANDICAP COMBO SHELL POUCH. Thank you for your attention to safety!