

CLUB SERIES RANGE BAG GREEN

BOB ALLEN CLUB SERIES RANGE BAG FEATURES: Ripstop nylon construction Padded interior pockets perfect for pistols Internal glasses and ear protection pockets Zippered front, back, and side pockets Magazine loops Wrap around handles with adjustable loops to carry baton or flashlight Adjustable shoulder strap Overall external measurements: 18" x 10" x 10"



Attributes

- Name: CLUB SERIES RANGE BAG GREEN
- Manufacturer: BOB ALLEN
- Product no.: 430113161
- Mfr. No.: 22173
- Color: Green
- Material: Nylon
- Style: Range Bag
- Shipping height: 254mm
- Shipping width: 254mm
- Shipping length: 457mm
- UPC: 617867122358

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BOB ALLEN CLUB SERIES RANGE BAG](#)

Safety Instruction Guide for BOB ALLEN CLUB SERIES RANGE BAG

Introduction

Thank you for choosing the BOB ALLEN CLUB SERIES RANGE BAG. This guide provides essential safety instructions to ensure the safe use and maintenance of your range bag. Please read this guide thoroughly before using the product.

General Safety Guidelines

- **Product Safety:** This range bag is designed for safe use. Always follow the instructions provided in this guide to minimize risks.
- **Enhanced Recalls:** In the event of a product recall, you will be notified through standardized recall notices. Please keep your purchase information for reference.
- **Online Shopping:** If purchased online, ensure that the retailer complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** This product is not intended for children. Keep it out of reach to ensure their safety.
- **EU Contact Point:** For any safety inquiries, refer to the appropriate EU-based contact.
- **Rapid Alerts:** Stay informed about any updates or alerts related to the product through the Safety Gate system.

Specific Safety Precautions for Use

- **Do not overload the bag:** Ensure that the bag is not overloaded to prevent damage to the zippers or seams.
- **Avoid exposure to extreme temperatures:** Do not leave the bag in direct sunlight or in extremely hot or cold conditions for prolonged periods.
- **Check for wear and tear:** Regularly inspect the bag for any signs of damage or wear that may compromise its safety and functionality.
- **Securely close all zippers:** Always ensure that all zippers are fully closed when not in use to prevent items from falling out.
- **Use handles and straps correctly:** When carrying the bag, use the wraparound handles or adjustable shoulder strap to avoid strain or injury.

Instructions for Installation and Usage

- **Unpacking the Bag:** Carefully remove the range bag from its packaging. Inspect the bag for any damage or missing components.
- **Organizing Your Gear:**
 - Use the padded interior pockets for pistols to ensure protection.
 - Store glasses and ear protection in the designated internal pockets.
 - Utilize the zippered front, back, and side pockets for additional gear.
 - Use magazine loops to keep magazines organized and secure.
- **Carrying the Bag:**
 - Adjust the shoulder strap for a comfortable fit.
 - Use the wraparound handles to carry the bag securely.
- **Cleaning and Maintenance:**
 - Clean the exterior with a damp cloth. Avoid using harsh chemicals.
 - Ensure that the interior is free from debris and moisture.

Disposal Instructions

- **Recycling:** When the bag has reached the end of its life, consider recycling it where facilities exist.
- **Waste Disposal:** If recycling is not an option, dispose of the bag in accordance with local waste disposal regulations.

Contact Information for Further Support

For any questions or concerns regarding the BOB ALLEN CLUB SERIES RANGE BAG, please refer to the retailer from whom you purchased the product. They will be able to assist you with any inquiries related to safety, usage, or warranty.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy using your BOB ALLEN CLUB SERIES RANGE BAG!