

INSERT-A-PAD - BOB ALLEN INSERT-A-PAD BLACK

[Shooting Accessories](#) > [Recoil Parts](#) > [Recoil Pads](#) > [Universal](#)

BOB ALLEN INSERT-A-PAD FEATURES: Color: Black High-density neoprene shooting pad Easily attaches to shooting garments with a safety pin Can also be used with clothing that features and Insert-A-Pad[®] pocket 4" L x .25" W x 7.25" H



Attributes

- Name: [BOB ALLEN INSERT-A-PAD BLACK](#)
- Manufacturer: [BOB ALLEN](#)
- Product no.: 430113165
- Mfr. No.: 1001
- Colour: Black
- Material: Neoprene
- Shipping height: 184mm
- Shipping width: 6mm
- Shipping length: 102mm
- UPC: 617867106051

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for BOB ALLEN INSERTAPAD BLACK](#)
- [About Us](#)

Safety Instruction Guide for BOB ALLEN INSERTAPAD BLACK

Introduction

Thank you for choosing the BOB ALLEN INSERTAPAD BLACK. This product is designed to enhance your shooting experience by providing comfort and stability. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always inspect the product before use for any signs of damage or wear.
- Ensure that the INSERTAPAD is compatible with your shooting garments.
- Keep this product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Material Safety:** The INSERTAPAD is made from highdensity neoprene. Ensure that you are not allergic to neoprene before use.
- **Proper Attachment:** Use the safety pin provided to securely attach the pad to your shooting garment. Ensure it is fastened correctly to avoid detachment during use.
- **Usage with Clothing:** If using with clothing that features an InsertAPad pocket, ensure that the pocket is clean and free from obstructions before inserting the pad.
- **Age Warning:** This product is not intended for children under 12 years of age. Adult supervision is recommended when used by younger individuals.

Instructions for Installation and Usage

1. Preparation:

- Before attaching the INSERTAPAD, ensure your shooting garment is clean and dry.
- Identify the location on your garment where you wish to attach the pad.

2. Attaching the Pad:

- Align the pad with the desired location on your garment.
- Use the safety pin to secure the pad. Ensure the pin goes through both the pad and the garment for a secure fit.
- If using with an InsertAPad pocket, slide the pad into the pocket ensuring it fits snugly.

3. Using the Pad:

- Once attached, check that the pad is secure before beginning your shooting practice.
- Adjust your shooting position as necessary to maximize comfort and stability with the pad in place.

4. PostUse Care:

- After use, carefully detach the pad from your garment.
- Clean the pad with a damp cloth if necessary and allow it to dry completely before storage.

Disposal Instructions

- Dispose of the INSERTAPAD responsibly.
- If the product is damaged or no longer needed, consider recycling it where facilities exist.
- Do not dispose of the product in regular household waste if it contains materials that can be recycled.

Contact Information for Further Support

For any inquiries regarding the safety or use of the BOB ALLEN INSERTAPAD BLACK, please refer to the manufacturer's website or contact their customer support.

By following these safety instructions, you can ensure a safer and more enjoyable experience with your BOB ALLEN INSERTAPAD BLACK. Thank you for prioritizing safety and responsible usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk