

TACTICAL ASSAULT BAG WITH RIFLE HOLDER BLACK

TACTICAL ASSAULT BAG WITH RIFLE HOLDER This Assault Pack provides roomy, durable transport for your supplies, clothes and equipment. Great for day trips, hunting and more. FEATURES: Padded back, shoulder straps and waist belt to carry a heavy load in comfort Fully padded compartment to carry a rifle Main compartment is 18 x 10 x 5" Rifle holder measures 42" from butt to barrel Has lid pocket and 2 side gear holders Modular straps for adding more gear Heavy-duty haul handle can be stowed inside lid 900-cu. in. capacity



Attributes

- Name: TACTICAL ASSAULT BAG WITH RIFLE HOLDER BLACK
- Manufacturer: SCHRECK WHOLESALE INC
- Product no.: 430114033
- Mfr. No.: TAC001
- Color: Black
- Cubic Inches: 2100
- Dimensions: 42" x 5" x 10"
- Weight: 4.5 lbs
- Delivery weight: 2.268kg
- Shipping height: 254mm
- Shipping width: 127mm
- Shipping length: 1,067mm
- UPC: 789232327986

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for TACTICAL ASSAULT BAG WITH RIFLE HOLDER](#)

Safety Instruction Guide for TACTICAL ASSAULT BAG WITH RIFLE HOLDER

Introduction

Thank you for choosing the TACTICAL ASSAULT BAG WITH RIFLE HOLDER. This product is designed to provide durable and spacious transport for your supplies, clothes, and equipment. It is essential to use this product safely and responsibly. This guide will provide you with important safety instructions and guidelines to ensure a safe experience.

General Safety Guidelines

- Always inspect the bag before use for any signs of damage or wear.
- Ensure that all zippers and straps are functioning correctly before carrying heavy loads.
- Keep the bag away from sharp objects and extreme heat to prevent damage.
- Store the bag in a dry place to avoid mold and deterioration of materials.
- Be mindful of the weight you carry to prevent strain or injury.

Specific Safety Precautions for Use

- **Weight Limit:** Do not exceed the recommended weight limit of the bag to ensure safe handling.
- **Child Safety:** This product is not intended for use by children under the age of 12 without adult supervision.
- **Rifle Storage:** Ensure that the rifle is unloaded and secured in the designated compartment before transport.
- **Secure Straps:** Always secure all straps when carrying the bag to prevent items from falling out.
- **Environmental Conditions:** Avoid using the bag in extreme weather conditions that may compromise its integrity.

Instructions for Installation and Usage

1. Packing the Bag:

- Open the main compartment and place your items inside.
- Use the fully padded compartment to securely store the rifle.
- Utilize the lid pocket and side gear holders for additional items.

2. Adjusting Straps:

- Adjust the shoulder straps and waist belt for a comfortable fit.
- Ensure that the padded back is aligned with your back for optimal support.

3. Carrying the Bag:

- Use the heavyduty haul handle for lifting when necessary.
- When carrying the bag on your back, ensure that it is balanced and not overly heavy on one side.

4. Cleaning and Maintenance:

- Wipe the exterior with a damp cloth to remove dirt.
- Allow the bag to air dry completely before storing it.

Disposal Instructions

- Dispose of the bag responsibly at a recycling facility that accepts fabric materials.
- If the bag is damaged beyond repair, ensure that it is disposed of in a way that prevents environmental harm.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact information provided with your product packaging.

This guide is designed to help you use the TACTICAL ASSAULT BAG WITH RIFLE HOLDER safely and effectively. Please follow all instructions and guidelines to ensure your safety and the longevity of the product.