

DIRTY BIRD QUICKDRAW 12 X 18" TARGETS - BIRCHWOOD CASEY

DIRTY BIRD QUICKDRAW 12 X 18" TARGETS 6 PACK

[Shooting Accessories](#) > [Targets & Accessories](#) > [Paper Targets](#)

BIRCHWOOD CASEY DIRTY BIRD QUICKDRAW 12 X 18" TARGETS FEATURES:
Spot your shots easily? Intense splatter offers superior downrange contrast?
Great targets for all types of pistol-action shooting? Heavy tagboard
construction 12" x 18"? 6 Pack



Attributes

- Name: [BIRCHWOOD CASEY DIRTY BIRD QUICKDRAW 12 X 18" TARGETS 6 PACK](#)
- Manufacturer: [BIRCHWOOD CASEY](#)
- Product no.: 430114043
- Mfr. No.: BC-35774
- Style: Bullseye
- Target Size/Type: Large 12 to 20
- Type: Papers
- Quantity: 6
- Delivery weight: 1.937kg
- Shipping height: 317mm
- Shipping width: 463mm
- Shipping length: 30mm
- UPC: 888151076569

Table of Contents

- [Startpage](#)
- [DIRTY BIRD QUICKDRAW 12 X 18" TARGETS SAFETY INSTRUCTION GUIDE](#)
- [About Us](#)

DIRTY BIRD QUICKDRAW 12 X 18" TARGETS

SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the DIRTY BIRD QUICKDRAW 12 X 18" TARGETS by Birchwood Casey. This guide provides important safety instructions and guidelines to ensure the safe use of your targets. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure that all users are familiar with the safe handling and use of firearms.
- Always treat every firearm as if it is loaded.
- Use targets in a safe and controlled environment, away from bystanders and unauthorized persons.
- Regularly inspect targets for any damage before use.
- Follow local laws and regulations regarding the use of targets and firearms.

Specific Safety Precautions for Use

- Always position targets in a suitable area that allows for a safe backstop to catch stray bullets.
- Avoid using targets in areas with high traffic or where people may inadvertently enter the shooting range.
- Ensure that all participants wear appropriate eye and ear protection while shooting.
- Do not use targets if they show signs of wear or damage, as this could lead to unpredictable results or safety hazards.
- Keep the shooting area clean and free of debris to prevent accidents.

Instructions for Installation and Usage

1. Installation:

- Choose a stable and secure location for mounting the targets.
- Use a suitable stand or holder that can support the target's weight and withstand shooting impacts.
- Ensure the target is positioned at a safe height and distance according to your shooting preferences and local regulations.

2. Usage:

- Set up the target at a safe distance, typically between 10 and 20 yards, depending on the type of shooting you are doing.
- Before shooting, ensure that the area is clear of people and obstacles.
- After shooting, inspect the target for any damage and ensure that all shots have been accounted for.

Disposal Instructions

- Dispose of used or damaged targets in accordance with local waste disposal regulations.
- Do not burn targets, as this may release harmful substances.
- If the targets are biodegradable, follow local guidelines for composting or recycling.

Contact Information for Further Support

For any questions or concerns regarding the DIRTY BIRD QUICKDRAW 12 X 18" TARGETS, please refer to the product's packaging or visit the manufacturer's website for additional resources and support.

Please remember that safety is a shared responsibility. By following these guidelines, you contribute to a safer shooting environment for yourself and others. Thank you for prioritizing safety while enjoying your shooting activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk