

12 GAUGE LEFT HAND TRIGGER PLATE FOR REMINGTON VERSA MAX - 12GA TRIGGER PLATE LEFT HAND FOR REMINGTON VERSA MAX BLACK

REMINGTON 12 GAUGE LEFT HAND TRIGGER PLATE FOR REMINGTON VERSA MAX Factory-style Left-Hand Trigger Plate designed for the Remington Versa Max II. Constructed from lightweight aluminum and finished in Black, this trigger plate is configured for left-hand safety orientation. Ideal for left-handed shooters or for replacing a damaged or worn factory unit. This aluminum trigger plate is manufactured to factory dimensions for proper fit within compatible Versa Max II shotguns. Designed specifically for left-hand (LH) safety configuration, it accommodates the cross-bolt safety setup oriented for left-handed operation. The black finish matches standard factory Versa Max II models. FEATURES Designed for Remington Versa Max II Left-Hand (LH) Safety Configuration Lightweight aluminum construction Factory-style Black finish Precision-machined for proper fit Ideal for repair or replacement SPECS Product Type: Trigger Plate Compatible Model: Remington Versa Max II Gauge: 12GA (verify model prior to purchase) Material: Aluminum Finish: Black Safety Configuration: Left-Hand Installation: Professional gunsmith installation recommended NOTE: These items are a new, authentic products acquired directly from Remington's OEM inventory. This item is guaranteed to be unused and fully functional.

NO IMAGE
AVAILABLE

Attributes

- Name: 12GA TRIGGER PLATE LEFT HAND FOR REMINGTON VERSA MAX BLACK
- Manufacturer: REMINGTON
- Product no.: 430116579
- Mfr. No.: F408602
- Model: Versamax
- Weapon type: Remington
- Delivery weight: 0.233kg

Item details

Made in USA

US export classification: 0A502

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for 12 GAUGE LEFT HAND TRIGGER PLATE FOR REMINGTON VERSA MAX](#)

Safety Instruction Guide for 12 GAUGE LEFT HAND TRIGGER PLATE FOR REMINGTON VERSA MAX

Introduction

Thank you for choosing the 12 Gauge Left Hand Trigger Plate designed for the Remington Versa Max II. This guide provides essential safety instructions and information for the proper use and installation of the product. It is important to follow these guidelines to ensure safe and effective operation.

General Safety Guidelines

- Always ensure that the firearm is unloaded before attempting any installation or maintenance.
- Use protective eyewear when handling or installing the trigger plate to prevent injury.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the trigger plate for signs of wear or damage.
- Only use the trigger plate with compatible Remington Versa Max II shotguns.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that you are using the trigger plate in the lefthand safety configuration as intended.
- Do not modify the trigger plate or attempt to use it in a way that it was not designed for.
- Always follow the manufacturer's instructions for your shotgun model.
- If you experience any malfunctions, cease use immediately and consult a professional gunsmith.

Instructions for Installation and Usage

1. Prepare Your Workspace

- Ensure you have a clean, welllit area to work in.
- Gather necessary tools, including a screwdriver and any other required equipment.

2. Remove the Existing Trigger Plate

- Ensure the shotgun is unloaded.
- Follow the manufacturer's instructions for disassembling the shotgun to access the trigger plate.

3. Install the New Trigger Plate

- Align the new lefthand trigger plate with the mounting points on the shotgun.
- Secure the trigger plate using the appropriate screws, ensuring they are tightened properly.

4. Check Functionality

- Once installed, conduct a function check of the trigger assembly.
- Ensure that the crossbolt safety operates smoothly and that the trigger mechanism functions correctly.

5. Reassemble the Shotgun

- Follow the manufacturer's instructions to reassemble your shotgun.
- Ensure all components are secured and functioning properly before use.

Disposal Instructions

- Dispose of any old or damaged trigger plates in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, consult local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the 12 Gauge Left Hand Trigger Plate, please contact the manufacturer or a qualified professional.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your 12 Gauge Left Hand Trigger Plate for the Remington Versa Max II. Always prioritize safety and seek professional assistance if you have any doubts or questions regarding installation or usage. Thank you for your attention to these important safety guidelines.