

MEC LEAD CHARGE BARS FOR SINGLE STAGE PRESS - MEC RELOADING 1-1/4OZ LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses.

MEC Lead Charge Bar 1-1/4 Ounce Single Stage Press



Attributes

- Name: [MEC RELOADING 1-1/4OZ LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749009376
- Mfr. No.: 302114
- Size: 1-1/4 oz
- Delivery weight: 0.249kg
- Shipping height: 24mm
- Shipping width: 24mm
- Shipping length: 162mm
- UPC: 098489014847

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bars for Single Stage Press Safety Instructions
- About Us

MEC Lead Charge Bars for Single Stage Press Safety Instructions

Introduction

Thank you for choosing the MEC Lead Charge Bar for your single stage reloading press. This guide provides essential safety instructions to ensure the safe use of this product. Please read this manual carefully before using the charge bar to avoid any potential hazards and to ensure a safe reloading experience.

General Safety Guidelines

- Always ensure that the work area is clean and free from any obstructions.
- Use protective eyewear and gloves when handling lead components to minimize exposure to lead dust.
- Keep the product out of reach of children and pets.
- Do not attempt to modify or alter the charge bar in any way.
- Ensure that all components are in good working order before use.
- Follow all local laws and regulations regarding the use and storage of ammunition components.

Specific Safety Precautions for Use

- Always verify that the press is securely mounted and stable before operation.
- Ensure that the charge bar is properly installed and locked into place before use.
- Never exceed the specified weight limit of the charge bar (11/4 oz).
- Do not leave the press unattended while in operation.
- Be cautious of hot surfaces and moving parts during operation.
- If you experience any unusual noises or resistance while using the charge bar, stop using the product immediately and inspect it for damage.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is turned off and unplugged.
- Remove any existing charge bar from the press.
- Align the MEC Lead Charge Bar with the mounting points on the press.
- Securely lock the charge bar in place according to the manufacturer's instructions.
- Doublecheck that the charge bar is properly installed before proceeding.

2. Usage

- Prepare the press by ensuring it is clean and free of debris.
- Measure the appropriate amount of lead shot (11/4 oz) for your load.
- Pour the lead shot into the charge bar's reservoir.
- Operate the press in accordance with the manufacturer's instructions for reloading.
- After use, clean the charge bar to remove any residue and prevent corrosion.

Disposal Instructions

- Dispose of any unused lead shot and lead components in accordance with local regulations for hazardous waste.
- Do not dispose of lead in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support regarding the MEC Lead Charge Bar, please refer to the manufacturer's website or contact your local MEC dealer.

By following these safety instructions, you can ensure a safe and efficient reloading experience with the MEC Lead Charge Bar. Always remain vigilant and prioritize safety when handling any reloading equipment. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk