

## JAE Accessories - M-LOK ARCA Rail 700 - 6" - BLK

[Rifle Parts](#) > [Forend & Handguard Parts](#) > [Handguard & Rail Accessories](#) > [Rail Covers](#)

Uniquely designed M-LOK ARCA RAIL runs the full length of the forend, plus extends 2" past the front of the chassis (ARCA-2) or 6" past the front of the chassis (ARCA-6).

NO IMAGE  
AVAILABLE

### Attributes

- Name: [JAE Accessories - M-LOK ARCA Rail 700 - 6" - BLK](#)
- Manufacturer: [MDT](#)
- Product no.: EU2010232
- Mfr. No.: 107235-BLK
- Color: Black
- Material: Aluminum
- Style: M-LOK
- Delivery weight: 0.35kg
- Shipping height: 147mm
- Shipping length: 1,725mm
- UPC: 682157410590

# Table of Contents

- [Startpage](#)
- [JAE Accessories MLOK ARCA Rail Safety Instruction Guide](#)
- [About Us](#)

# JAE Accessories MLOK ARCA Rail Safety Instruction Guide

## Introduction

Thank you for choosing the JAE Accessories MLOK ARCA Rail. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before using the rail to understand the potential hazards and how to avoid them.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the product for any signs of wear or damage before each use.
- Do not modify or alter the product in any way, as this may compromise its safety and functionality.
- In case of any malfunction or damage, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as eye protection, when handling or installing the rail.
- Ensure that the installation area is clean and free from any obstructions that may cause accidents.
- Use only compatible accessories and components with the MLOK ARCA Rail to maintain safety and performance.
- Avoid overtightening screws and fasteners during installation to prevent damage to the rail or the chassis.
- Do not exceed the weight limits specified for the rail to prevent failure during use.

## Instructions for Installation and Usage

### 1. Preparation

- Gather all necessary tools and components before starting the installation.
- Read the product specifications to ensure compatibility with your chassis.

### 2. Installation Steps

- Locate the MLOK slots on your chassis.
- Align the MLOK ARCA Rail with the slots, ensuring a secure fit.
- Insert the provided screws into the MLOK slots and tighten them using a suitable tool. Do not overtighten.
- Ensure the rail is securely attached and does not move when pulled or pushed.

### 3. Usage Guidelines

- Once installed, use the rail to attach compatible accessories as needed.
- Regularly check the rail for stability and security during use, especially after any significant movement or adjustment.
- Follow the manufacturer's guidelines for any accessories used with the rail to ensure safe operation.

## Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic waste and materials.
- Do not dispose of the product in regular household waste.
- If you are unsure about disposal methods, consult your local waste management authority for guidance.

## Contact Information for Further Support

For safety inquiries or assistance regarding your JAE Accessories MLOK ARCA Rail, please refer to the official website or contact the manufacturer directly.

By following these safety instructions, you can ensure a safe and enjoyable experience with your JAE Accessories MLOK ARCA Rail. Thank you for your attention to safety!

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)