

Chronographs Replacement Parts - V3 Replacement Screw Kit Pack

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

This handy replacement screw kit for the MagnetoSpeed V3 Chronograph includes:

2 screws in three sizes: 7/16 in (1.11 cm), 1/2 in (1.27 cm), and 3/4 in (1.91 cm)
Includes matching hex key for easy installation

NO IMAGE
AVAILABLE

Attributes

- Name: [V3 Replacement Screw Kit Pack](#)
- Manufacturer: [MAGNETOSPEED](#)
- Product no.: EU2016415
- Mfr. No.: V3_K1_07
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [Chronographs Replacement Parts V3 Replacement Screw Kit Pack Safety Instructions](#)
- [About Us](#)

Chronographs Replacement Parts V3 Replacement Screw Kit Pack Safety Instructions

Introduction

Thank you for choosing the Chronographs Replacement Parts V3 Replacement Screw Kit Pack. This product is designed to provide you with essential replacement screws for your MagnetoSpeed V3 Chronograph. Please read these safety instructions carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle the screws and hex key with care to avoid injury.
- Ensure that the product is used only for its intended purpose as specified in the product description.
- Keep the product out of reach of children and vulnerable individuals to prevent accidental injury.
- Inspect the screws and hex key for any signs of damage before use. Do not use damaged parts.
- Report any unsafe products or accidents to the relevant authorities immediately.
- Regularly check for recall updates on the EU's Safety Gate platform to stay informed about any safety notices related to this product.

Specific Safety Precautions for Use

- Use the replacement screws only with the MagnetoSpeed V3 Chronograph to avoid compatibility issues.
- Ensure that the screws are tightened securely but do not overtighten, as this may damage the chronograph or the screws.
- When using the hex key, apply appropriate force and avoid using excessive pressure to prevent slipping and potential injury.
- If you are unsure about the installation process, seek assistance from a knowledgeable individual or professional.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including the replacement screws and the matching hex key provided in the kit.
- Ensure you are working in a welllit area to see all components clearly.

2. Installation Steps:

- Identify the screws that need replacement on your MagnetoSpeed V3 Chronograph.
- Remove the damaged screws using the hex key. Turn counterclockwise until the screws are completely removed.
- Select the appropriate replacement screw size (7/16 in, 1/2 in, or 3/4 in) based on the original screw size.
- Insert the new screw into the designated hole and use the hex key to turn clockwise until the screw is securely in place.
- Repeat the process for any additional screws that need replacement.

3. PostInstallation Check:

- Once all screws are installed, check that they are tightened properly. Ensure there is no wobbling or looseness.

- Test the functionality of the MagnetoSpeed V3 Chronograph to ensure proper operation.

Disposal Instructions

- Dispose of any old screws and packaging materials in accordance with your local waste disposal regulations.
- Do not dispose of the product in regular household waste if local regulations require special disposal methods for electronic components.

Contact Information for Further Support

For any questions or concerns regarding safety or usage of the Chronographs Replacement Parts V3 Replacement Screw Kit Pack, please refer to the manufacturer's contact information provided with your product packaging.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk