

Seater Head 5,60/.223-R73

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 5,60/.223-R73](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017391
- Mfr. No.: 3000054V-05.60-R073
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R73
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R073

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 5,60/.223R73. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure the product is used in accordance with the manufacturer's instructions.
- Inspect the Seater Head before each use for any signs of damage or wear.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as specified by the manufacturer.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may lead to personal injury or damage to equipment.
- Ensure that all components are compatible to avoid malfunctions.

- **Avoiding Hazards:**

- Do not exceed the recommended specifications for the Seater Head.
- Always wear appropriate safety gear, such as safety glasses and gloves, when using the product.
- Do not use the Seater Head if it is damaged or if there are any doubts about its integrity.

- **Age and AudienceSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18 without adult supervision.
- Ensure that inexperienced users are trained on the proper use of the product.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading setup is clean and free from debris.
2. Select the correct seater head using the tool on the manufacturer's website www.triebelreloading.com.
3. Securely attach the Seater Head to your reloading die, ensuring it is tightened according to the manufacturer's specifications.

- **Usage:**

1. Place the cartridge case in the reloading press.
2. Align the bullet with the mouth of the cartridge case.
3. Gradually lower the Seater Head to seat the bullet into the cartridge case.
4. Monitor the seating depth and adjust as necessary for optimal performance.
5. After use, clean the Seater Head to maintain its condition and performance.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the product in household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the appropriate customer service for assistance.

By following these safety instructions, you can ensure a safe and effective experience with the Seater Head 5,60/.223R73. Thank you for your attention to safety and for choosing our product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk