

Seater Head 6,00/.243-K12,5

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-K12,5
- Manufacturer: TRIEBEL
- Product no.: EU2017395
- Mfr. No.: 3000054V-06.00-K12.5
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: K12
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-K12.5

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243K12,5. This guide provides important safety instructions to ensure the safe handling and use of this product. It is essential to follow these guidelines to prevent accidents and ensure optimal performance.

General Safety Guidelines

- **Product Safety:** This product has been designed and manufactured to meet safety standards. Always ensure safe use when handling nonfood products.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to this product. Follow the manufacturer's instructions regarding returns or exchanges if necessary.
- **Online Shopping:** Ensure you are purchasing from trusted sources. Verify that the online platform complies with safety requirements.
- **Special Consumer Focus:** Extra precautions should be taken when this product is used around vulnerable groups, such as children.
- **EU Contact Point:** For any safety inquiries about this product, please refer to the manufacturer's website for contact details.
- **Rapid Alerts:** Stay updated on any safety alerts regarding this product through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the seater head.
- Ensure that the workspace is clean and free from any obstructions that may cause accidents.
- Do not use the seater head if it appears damaged or worn. Inspect the product before each use.
- Keep the seater head out of reach of children and pets to prevent accidental injuries.
- Follow all instructions related to the correct usage of the seater head to avoid misalignment and potential hazards.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website to select the correct seater head for your specific needs.

2. Installation:

- Ensure that your reloading die is clean and free from debris.
- Carefully insert the seater head into the reloading die, ensuring it is securely fitted.
- Tighten the locking mechanism to hold the seater head in place.

3. Usage:

- Adjust the seating depth according to your specifications.
- Place the cartridge case into the reloading press and align it properly.
- Gently lower the press handle to seat the bullet. Ensure the bullet is seated straight and at the desired depth.
- Inspect the completed cartridge for any irregularities before use.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the seater head is no longer usable, follow local guidelines for the disposal of metal objects.
- Do not dispose of the product in household waste. Check for recycling options in your area.

Contact Information for Further Support

For any questions or concerns regarding the use or safety of the Seater Head 6,00/.243K12,5, please refer to the manufacturer's website for further support and guidance.