

Seater Head 6,50/.264-K15

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-K15](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017405
- Mfr. No.: 3000054V-06.50-K15
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: K15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-K15

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264K15. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read this guide carefully before using the Seater Head and keep it for future reference.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always wear appropriate eye protection when reloading ammunition.
- Keep the work area clean and free from obstructions to prevent accidents.
- Store the Seater Head in a dry, secure place away from children and unauthorized users.
- Regularly inspect the Seater Head for signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding ammunition reloading and usage.

Specific Safety Precautions for Use

- Use the Seater Head only for its intended purpose, which is bullet seating.
- Do not exceed the recommended specifications for bullet and cartridge dimensions.
- Always ensure that the Seater Head is securely attached to the reloading press before use.
- Avoid wearing loose clothing or jewelry that may get caught in the reloading equipment.
- Keep hands and other body parts away from the moving parts of the reloading press during operation.
- If you experience any unusual noises or malfunctions during use, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Select the appropriate Seater Head for your bullet specifications using the tool on the manufacturer's website (www.triebelreloading.com).
- Ensure that the reloading press is turned off and unplugged before installation.
- Carefully screw the Seater Head into the designated position on the reloading press until it is snug. Do not overtighten.
- Check that the Seater Head is properly aligned and securely fastened.

2. Usage:

- Prepare your reloading components, including cases, primers, powder, and bullets.
- Set the desired seating depth according to your specifications.
- Place a prepared case into the reloading press and ensure it is properly positioned.
- Insert a bullet into the case mouth.
- Activate the reloading press to seat the bullet. Monitor the process closely to ensure proper seating.
- After seating, inspect the cartridge for proper bullet alignment and depth.

Disposal Instructions

- Dispose of any damaged or unusable Seater Heads in accordance with local waste disposal regulations.
- Do not throw the Seater Head in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please consult the manufacturer's website or contact their customer service for assistance.

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience with your Seater Head 6,50/.264K15. Always prioritize safety and compliance with local regulations while using this product. Thank you for your attention and safe reloading!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk