

Seater Head 7,00/.284-R30

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R30
- Manufacturer: TRIEBEL
- Product no.: EU2017428
- Mfr. No.: 3000054V-07.00-R030
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R30
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R030

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R30. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always handle the Seater Head with care to prevent injury.
- Ensure that you are using the Seater Head with compatible equipment.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all manufacturer instructions and guidelines for use.

Specific Safety Precautions for Use

• Hazard Identification:

- Improper use may result in injury or damage to the equipment.
- Ensure that the Seater Head is securely attached to the reloading die before use.

• Avoiding Hazards:

- Always wear appropriate safety gear, including eye protection, when using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head.
- Only use the Seater Head with original dies from Triebel Waffenwerkzeuge.

• Age and AudienceSpecific Warnings:

- This product is intended for use by adults only. Keep out of reach of children.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading die is clean and free from debris.
- Carefully screw the Seater Head into the reloading die until it is securely in place.
- Check for proper alignment and ensure that it is fixed tightly.

2. Usage:

- Set your reloading press to the appropriate settings for the caliber you are working with.
- Insert the cartridge case into the press and position the bullet above the case.
- Slowly lower the press handle to seat the bullet gently into the cartridge case.
- Inspect the seated bullet for proper alignment and depth after seating.

Disposal Instructions

- Dispose of the Seater Head according to local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further assistance, please refer to the manufacturer's website or contact the appropriate support channels.

By following these guidelines, you can ensure safe and effective use of the Seater Head 7,00/.284R30. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.