

Seater Head 7,00/.284-R165

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R165
- Manufacturer: TRIEBEL
- Product no.: EU2017437
- Mfr. No.: 3000054V-07.00-R165
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R16
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R165

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R165. This guide provides essential safety instructions and information to ensure the safe use and handling of this product. Please read this guide carefully before using the Seater Head to understand the necessary precautions and procedures.

General Safety Guidelines

- Always handle the Seater Head with care to avoid injury.
- Ensure that you are using the Seater Head with compatible reloading dies from Triebel Waffenwerkzeuge.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear before each use.
- Follow all manufacturer instructions and recommendations to ensure safe operation.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear safety glasses and gloves when handling the Seater Head to protect against potential injuries.
- **Work Environment:** Use the Seater Head in a welllit and clutterfree workspace to minimize the risk of accidents.
- **Compatibility:** Verify that the Seater Head is compatible with your reloading setup before use. Refer to the manufacturer's website for compatibility information.
- **Proper Handling:** Avoid applying excessive force when seating bullets. This can lead to misalignment and potential hazards.
- **Storage:** Store the Seater Head in a secure location when not in use to prevent accidents and unauthorized access.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your reloading press is clean and in good working condition.
- Gather all necessary tools and components required for the reloading process.

2. Installation:

- Carefully screw the Seater Head into the reloading die according to the manufacturer's instructions.
- Ensure it is securely tightened but avoid overtightening, which can damage the threads.

3. Usage:

- Insert the appropriate cartridge case into the reloading press.
- Place the bullet on top of the cartridge case.
- Operate the reloading press to seat the bullet gently using the Seater Head.
- Monitor the seating depth and ensure proper alignment throughout the process.

4. PostUse:

- After completing your reloading session, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in its designated storage area.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal and brass recycling.
- Do not discard in regular household waste.
- If the Seater Head is damaged beyond use, ensure it is disposed of safely to prevent injury.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website at www.tribelreloading.com. They provide resources and contact information for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,00/.284R165. Always prioritize safety and compliance with guidelines to protect yourself and others while using this product. Thank you for your attention to these important safety measures.