

Seater Head 7,62/.30-R50

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R50](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017445
- Mfr. No.: 3000054V-07.62-R050
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R050

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R50. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. It is essential to follow the safety guidelines outlined in this document to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always read and understand the manufacturer's instructions before use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the product.
- Ensure that the workspace is clean and free from obstructions to prevent accidents.
- Avoid using the product in wet or damp conditions to minimize electrical hazards.
- Do not exceed the recommended specifications for the product, including the diameter and radius.
- If you notice any unusual behavior during use, stop immediately and inspect the product.

Instructions for Installation and Usage

1. Installation:

- Ensure that you have the correct Seater Head for your specific die set. Refer to the manufacturer's website for guidance.
- Securely attach the Seater Head to the die, ensuring it is properly aligned and tightened to avoid any movement during use.

2. Usage:

- Load the cartridge case into the reloading press according to the manufacturer's instructions.
- Place the bullet into the cartridge case, ensuring it is seated properly.
- Adjust the seating depth as necessary by turning the adjustment screw on the die.
- Apply consistent pressure while operating the reloading press to ensure uniform bullet seating.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the product responsibly in accordance with local regulations.
- Do not dispose of the product in regular household waste if it contains hazardous materials.
- Check with local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact your local distributor. It is important to ensure that you have the latest information regarding product safety and

compliance.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,62/.30R50. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk