

Seater Head 7,62/.30-R60B

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R60B](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017447
- Mfr. No.: 3000054V-07.62-R060B
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 60B
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R060B

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R60B. This product is designed for precise and gentle bullet seating, ensuring optimal performance for your reloading needs. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only by individuals who are knowledgeable about reloading practices.
- Always follow the manufacturer's instructions and guidelines when using the Seater Head.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Ensure that the workspace is clean and free from distractions to avoid accidents during use.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Avoid using the product if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Carefully remove the existing seater head from the die set.
- Align the Seater Head 7,62/.30R60B with the die and screw it in securely, ensuring it is properly tightened.
- Check that the Seater Head is seated correctly and is stable before proceeding.

2. Usage:

- Prepare your cartridge cases and bullets according to the reloading guidelines.
- Insert the cartridge case into the die and ensure it is properly aligned.
- Place the bullet on top of the cartridge case.
- Activate the reloading press to gently seat the bullet into the case. Monitor the process to ensure proper alignment.
- After seating, inspect the cartridge for any irregularities or misalignment.

Disposal Instructions

- Dispose of the Seater Head responsibly at the end of its life cycle.
- Follow local regulations for the disposal of brass and other materials.
- Do not dispose of the product in regular household waste.
- Consider recycling the product if possible.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for support and additional resources.

Thank you for your attention to these safety guidelines. Safe reloading practices will help ensure your safety and the effectiveness of your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk