

Seater Head 7,62/.30-R70

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R70](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017450
- Mfr. No.: 3000054V-07.62-R070
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 70
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R070

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R70. This guide provides important safety instructions and guidelines to ensure the safe use of this product. Please read and understand all instructions before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling and using the Seater Head.
- Ensure that the work area is clean, dry, and welllit to prevent accidents.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Do not exceed the specified limits for bullet seating as indicated by the manufacturer.
- Be aware of the potential for small parts to pose choking hazards, especially if used in environments with children.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and disconnected from any power source.
- Select the appropriate seater head using the tool on the manufacturer's website www.triebelreloading.com.
- Carefully install the Seater Head into the die by following the manufacturer's instructions for your specific reloading press model.
- Tighten securely, but do not overtighten to avoid damage.

2. Usage:

- Adjust the Seater Head to the desired seating depth as per your reloading specifications.
- Place the cartridge case in the reloading press and ensure it is properly aligned with the Seater Head.
- Operate the reloading press smoothly to seat the bullet gently and accurately.
- After use, remove the Seater Head and clean it to maintain its precision and performance.

Disposal Instructions

- Dispose of any damaged or wornout components of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Instead, check with local recycling centers for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further support, please refer to the manufacturer's website or your local distributor for assistance.

By following these guidelines, you can ensure the safe and effective use of the Seater Head 7,62/.30R70. Remember to stay informed about safety updates and product recalls through the EU's Safety Gate platform. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk