

Seater Head 7,62/.30-R100

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,62/.30-R100](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017456
- Mfr. No.: 3000054V-07.62-R100
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 100
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R100

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R100. This guide provides essential safety instructions and guidelines to ensure the safe usage of this product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before each use.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Follow all safety regulations and guidelines when handling ammunition components.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Avoid using the Seater Head in wet or humid environments to prevent corrosion and ensure effective performance.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure proper ventilation in your workspace to avoid inhaling any dust or particles produced during use.
- Always follow the manufacturer's instructions for the specific die and cartridge being used.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials, including the Seater Head, compatible die, and ammunition components.
- Ensure your workspace is clean and organized.

2. Installation

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the compatible die according to the manufacturer's instructions.
- Ensure that the Seater Head is securely fastened and properly aligned.

3. Usage

- Load the cartridge case into the die as per the instructions provided with the die.
- Adjust the seating depth according to your specific requirements.
- Operate the reloading press smoothly and steadily to ensure consistent bullet seating.
- After use, clean the Seater Head and store it in a safe, dry place.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal recycling.
- Do not dispose of any ammunition components or materials in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for contact details and additional resources.

By following these safety instructions, you can ensure the safe and effective use of the Seater Head 7,62/.30R100. Thank you for prioritizing safety in your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk