

Seater Head 7,62/.30-R240

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,62/.30-R240
- Manufacturer: TRIEBEL
- Product no.: EU2017465
- Mfr. No.: 3000054V-07.62-R240
- Diameter (in): 0.30
- Diameter mm: 7,62
- Radius: 240
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.62-R240

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,62/.30R240. This guide provides essential safety instructions to ensure the safe use of this product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- **Product Safety:** Always ensure that the Seater Head is used in accordance with the manufacturer's guidelines to minimize risks associated with reloading ammunition.
- **Enhanced Recalls:** Stay informed about any product recalls. If a recall occurs, follow the instructions provided for returning or replacing the product.
- **Online Shopping:** When purchasing online, ensure you buy from reputable sources that comply with safety standards.
- **Special Consumer Focus:** Keep this product out of reach of children and vulnerable individuals. It is intended for use by knowledgeable adults only.
- **EU Contact Point:** For any safety inquiries, please refer to the manufacturer's contact information available on their website.
- **Rapid Alerts:** Regularly check the EU's Safety Gate platform for updates on product safety and potential hazards.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses and gloves, when handling the Seater Head and during the reloading process.
- **Work Area:** Use the Seater Head in a wellventilated area, free from distractions and hazards.
- **Inspection:** Before each use, inspect the Seater Head for any signs of damage or wear. Do not use if it appears damaged.
- **Compatibility:** Ensure that the Seater Head is compatible with your reloading dies. Refer to the manufacturer's website for compatibility information.
- **Proper Handling:** Handle the Seater Head with care. Avoid dropping or mishandling to prevent damage.
- **Storage:** Store the Seater Head in a safe, dry place when not in use, away from children and pets.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is clean and free from debris.
- Carefully screw the Seater Head into the appropriate die in your reloading press, following the manufacturer's instructions.
- Tighten securely but do not overtorque, as this may damage the Seater Head or die.

2. Usage:

- Prepare your cartridges according to standard reloading practices.
- Place the bullet in the case mouth and align it with the Seater Head.
- Gradually apply pressure to the reloading press handle to seat the bullet. Monitor the process to ensure proper seating depth.
- After use, clean the Seater Head to maintain its precision and functionality.

Disposal Instructions

- Dispose of the Seater Head responsibly. If it is damaged or no longer usable, follow local regulations for disposing of metal products.
- Do not dispose of the Seater Head in regular household waste. Check with local authorities for recycling options or hazardous waste disposal sites.

Contact Information for Further Support

For assistance, please refer to the manufacturer's website for support resources, including FAQs, troubleshooting guides, and contact details for customer service.

By following these safety instructions, you can help ensure a safe and effective reloading experience with your Seater Head 7,62/.30R240. Always prioritize safety and compliance with all relevant regulations.