

Seater Head 8,08/.318-K8

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,08/.318-K8
- Manufacturer: TRIEBEL
- Product no.: EU2017469
- Mfr. No.: 3000054V-08.08-K08
- Diameter (in): 0.318
- Diameter mm: 8,08
- Radius: K8
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.08-K08

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,08/.318K8. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Inspect the product before use for any signs of damage or wear.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head in a wellventilated area to avoid inhalation of any particles.
- Report any unsafe products or accidents to the relevant authorities.
- Check for product recalls on the EU's Safety Gate platform to stay informed about safety updates.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - The Seater Head may have sharp edges. Handle with care to avoid cuts.
 - Improper use may lead to misalignment, resulting in inaccurate bullet seating.
- **Avoiding Hazards:**
 - Always wear safety glasses when using the Seater Head to protect your eyes.
 - Use appropriate gloves to protect your hands from sharp edges.
 - Ensure that the Seater Head is securely attached to the reloading die before use.
 - Do not exceed the recommended specifications for bullet seating as indicated on the manufacturer's website.
- **Age Restrictions:**
 - This product is not intended for use by individuals under the age of 18 without adult supervision.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading die is clean and free from any obstructions.
 2. Carefully insert the Seater Head into the reloading die.
 3. Securely tighten the Seater Head to ensure it is firmly in place.
 4. Check alignment to ensure proper positioning.
- **Usage:**
 1. Place the cartridge case into the reloading press.
 2. Insert the bullet into the case.
 3. Slowly lower the reloading press handle to seat the bullet.
 4. Check the seating depth to ensure it meets your specifications.
 5. Repeat the process for additional cartridges, ensuring consistent seating.

Disposal Instructions

- Dispose of the Seater Head responsibly:
 - If the product is damaged or no longer usable, check local regulations for metal recycling options.
 - Do not dispose of the Seater Head in regular household waste.
 - Ensure that any hazardous materials are disposed of according to local environmental regulations.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the manufacturer's website or contact your local distributor. It is important to have access to reliable information regarding the safe use of your Seater Head.

Thank you for following these safety instructions. Your adherence to these guidelines will help ensure a safe and effective reloading experience with the Seater Head 8,08/.318K8.