

Seater Head 8,17/.322-R16

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,17/.322-R16](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017474
- Mfr. No.: 3000054V-08.17-R016
- Diameter (in): 0.322
- Diameter mm: 8,17
- Radius: R16
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.17-R016

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,17/.322R16 by TRIEBEL. This guide provides essential safety instructions and information to ensure safe and effective use of the product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always inspect the product for any damage before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use protective eyewear when operating the Seater Head to prevent eye injuries.
- Store the Seater Head in a dry and safe location when not in use.
- Report any unsafe products or accidents to the relevant authorities immediately.
- Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- Handle the Seater Head with care to avoid injury.
- Ensure that the Seater Head is compatible with your reloading equipment before use.
- Do not exceed the recommended specifications for bullet seating.
- Use only the correct seater head as indicated on the manufacturer's website.
- Avoid using the Seater Head in wet or damp conditions to prevent accidents.
- Be cautious of any sharp edges or points on the Seater Head.

Instructions for Installation and Usage

1. **Check Compatibility:** Verify that the Seater Head is suitable for your original dies from Triebel Waffenwerkzeuge.
2. **Prepare Your Equipment:** Ensure that your reloading equipment is clean and in good working condition.
3. **Install the Seater Head:**
 - Remove the existing seater head from your die.
 - Carefully screw the new Seater Head into the die until it is securely fastened.
 - Ensure it is properly aligned for optimal performance.
4. **Adjust Settings:** Set the seating depth according to your specifications and the type of bullets you are using.
5. **Begin Reloading:**
 - Insert the cartridge case into the reloading press.
 - Operate the press to seat the bullet gently and precisely.
 - Monitor the process to ensure that the bullet is seated correctly.
6. **PostUse Care:** After use, clean the Seater Head to maintain its condition and performance.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the Seater Head is no longer usable, dispose of it responsibly. Check local guidelines for proper disposal methods for metal products.
- Do not throw the Seater Head in regular household waste if it is still in working condition; consider donating or recycling.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's website for contact details and additional support resources.

Thank you for prioritizing safety while using the Seater Head 8,17/.322R16. Following these guidelines will help ensure a safe and successful reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk