

Seater Head 8,20/.323-R62

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,20/.323-R62](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017481
- Mfr. No.: 3000054V-08.20-R062
- Diameter (in): 0.323
- Diameter mm: 8,20
- Radius: R62
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.20-R062

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 8,20/.323R62. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure you are using the Seater Head in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use appropriate personal protective equipment (PPE) such as safety glasses when handling and operating reloading equipment.
- Be aware of your surroundings and ensure a clean, organized workspace while using the Seater Head.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading dies. Refer to the manufacturer's website for compatibility information.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- When adjusting the Seater Head, make sure it is securely fastened to prevent accidental movement during operation.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure consistent performance.
- If you encounter any issues during use, stop immediately and consult the troubleshooting section of your reloading manual.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including your reloading press and appropriate dies.
- Ensure your workspace is clean and free from distractions.

2. Installation:

- Identify the correct Seater Head for your reloading setup using the tool on the manufacturer's website.
- Securely attach the Seater Head to the reloading press according to the manufacturer's guidelines.
- Doublecheck that the Seater Head is properly aligned and fastened.

3. Usage:

- Begin by adjusting the Seater Head to the desired seating depth as specified in your reloading manual.
- Insert the cartridge case into the reloading press and position the bullet above the case mouth.
- Operate the press smoothly and steadily to seat the bullet. Avoid sudden movements or excessive force.
- After seating, inspect the cartridge for proper alignment and depth.

4. PostUsage:

- After use, clean the Seater Head to remove any residue or debris.
- Store the Seater Head in a safe, dry place away from direct sunlight and moisture.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads according to local regulations for metal recycling.
- Do not throw the Seater Head in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's website or contact the authorized distributor in your region.

Thank you for taking the time to read and understand these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk