

Seater Head 8,21/.323-K8

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 8,21/.323-K8
- Manufacturer: TRIEBEL
- Product no.: EU2017485
- Mfr. No.: 3000054V-08.21-K08
- Diameter (in): 0.323
- Diameter mm: 8,21
- Radius: K8
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.21-K08

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,21/.323K8. This product is designed for precision bullet seating and is made from highquality brass. It is essential to follow safety guidelines and instructions to ensure safe and effective use of this product.

General Safety Guidelines

- Ensure all safety measures are followed to prevent accidents and injuries.
- Always handle the Seater Head with care to avoid damage and ensure longevity.
- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Regularly inspect the Seater Head for signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when using the Seater Head.
- Avoid using the Seater Head if you are under the influence of alcohol, drugs, or any substances that may impair your judgment.
- Ensure that the workspace is clean and free of any hazards that could lead to accidents.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius, to prevent malfunction.
- If you notice any unusual sounds or resistance while using the Seater Head, stop immediately and inspect the tool.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting.
- Ensure the workspace is welllit and organized.

2. Installation:

- Select the appropriate Seater Head for your specific needs using the tool available on the manufacturer's website, www.triebelreloading.com.
- Carefully attach the Seater Head to the compatible die, ensuring a secure fit.

3. Usage:

- Load the cartridge case into the die.
- Adjust the Seater Head to the desired depth based on your specifications.
- Slowly and gently apply pressure to seat the bullet. Avoid using excessive force.
- After seating the bullet, inspect the cartridge for proper alignment and fit.

4. PostUsage:

- Clean the Seater Head after each use to maintain its precision and functionality.
- Store the Seater Head in a safe, dry place when not in use.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Ensure that all components are disposed of in an environmentally friendly manner.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the designated EU contact point.

Conclusion

By adhering to these safety instructions, you can ensure the safe and effective use of the Seater Head 8,21/.323K8. Always prioritize safety and take the necessary precautions to protect yourself and others during use. Thank you for your attention to these important guidelines.