

Seater Head 8,50/.338-R90

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 8,50/.338-R90](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017495
- Mfr. No.: 3000054V-08.50-R090
- Diameter (in): 0.338
- Diameter mm: 8,50
- Radius: R90
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-08.50-R090

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 8,50/.338R90. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully. It outlines essential safety guidelines, precautions, installation instructions, and disposal information in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always follow safety instructions during use to prevent accidents and injuries.
- Ensure that the product is suitable for your specific reloading needs and equipment.
- Regularly inspect the product for signs of wear or damage before each use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use only with original dies from Triebel Waffenwerkzeuge to ensure compatibility and safety.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading equipment.
- Ensure that your workspace is clean and free from clutter to avoid accidents.
- Do not exceed recommended pressure limits when seating bullets.
- Avoid using excessive force during the bullet seating process to prevent damage to the product or injury.
- Store the product in a dry, cool place to prevent corrosion and deterioration.

Instructions for Installation and Usage

1. Selecting the Seater Head:

- Use the tool on the manufacturer's website (www.triebelreloading.com) to select the correct seater head for your needs.

2. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the reloading die.
- Carefully install the Seater Head 8,50/.338R90 into the die, ensuring it is securely fastened.
- Check that the seater head is properly aligned and functioning smoothly.

3. Usage:

- Prepare your cartridges according to standard reloading procedures.
- Insert the bullet into the case mouth before seating.
- Gently lower the ram of the reloading press to seat the bullet.
- Monitor the seating depth and make adjustments as necessary to achieve desired results.
- After use, clean the seater head and store it properly to maintain its condition.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding metal and electronic waste.
- Do not dispose of the product in general household waste.

- Consider recycling the brass material where applicable.

Contact Information for Further Support

For any inquiries regarding product safety or support, please refer to the manufacturer's website or contact your local distributor.

Thank you for taking the time to read this safety instruction guide. Your safety and satisfaction are our top priorities. Enjoy your reloading experience with the Seater Head 8,50/.338R90!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk