

Seater Head 9,00/.358-K11

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,00/.358-K11](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017502
- Mfr. No.: 3000054V-09.00-K11
- Diameter (in): 0.358
- Diameter mm: 9,00
- Radius: K11
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.00-K11

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,00/.358K11. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always handle the Seater Head with care to prevent injury.
- Ensure that you are using the Seater Head with compatible equipment.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use protective eyewear when operating the Seater Head to prevent eye injuries from debris.
- Ensure that your workspace is clean and free of obstructions to prevent accidents.
- Do not exceed the recommended specifications for the Seater Head to avoid malfunction.
- Always follow the manufacturer's instructions for installation and use to ensure safety.
- Avoid using the Seater Head if you are tired or under the influence of substances that may impair your judgment.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading press is turned off and unplugged before installation.
- Select the correct seater head using the tool on the manufacturer's website: www.tribelreloading.com.
- Securely attach the Seater Head to the reloading press according to the manufacturer's instructions.

2. Usage

- Before starting, doublecheck that all components are properly secured and aligned.
- Load the cartridge case into the reloading press according to the manufacturer's guidelines.
- Carefully insert the bullet into the case mouth.
- Activate the reloading press to seat the bullet. Monitor the process to ensure proper seating without excessive force.
- After use, clean the Seater Head and store it in a safe location.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in household waste if it is damaged or contains hazardous materials.
- Consider recycling options for brass components if available in your area.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Seater Head, please refer to the manufacturer's

website or customer service.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk