

Seater Head 9,30/.366-R24

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,30/.366-R24](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017506
- Mfr. No.: 3000054V-09.30-R024
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R24
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R024

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366R24. This product is designed for precise and gentle bullet seating, enhancing your cartridge accuracy. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the Seater Head according to the manufacturer's instructions.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Inspect the Seater Head for any damage or defects before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Personal Safety:** Always wear appropriate safety gear, including safety glasses and gloves, when using reloading equipment.
- **Work Environment:** Use the Seater Head in a wellventilated area, free from distractions.
- **Handling:** Handle the Seater Head with care to avoid dropping it or causing any impact damage.
- **Storage:** Store the Seater Head in a secure location when not in use to prevent unauthorized access.

Instructions for Installation and Usage

1. Compatibility Check:

- Verify that the Seater Head is suitable for your original Triebel dies.
- Use the manufacturer's website tool to confirm compatibility.

2. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your die if applicable.
- Carefully install the Seater Head into the die, ensuring a secure fit.
- Tighten the seater head according to the manufacturer's specifications.

3. Usage:

- Set the desired bullet seating depth according to your reloading specifications.
- Insert the cartridge case into the reloading press.
- Gently lower the Seater Head to seat the bullet, ensuring proper alignment.
- Check the cartridge for proper seating and alignment after each operation.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Check for recycling options or hazardous waste disposal facilities in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for support and additional resources.

Thank you for prioritizing safety while using the Seater Head 9,30/.366R24. Your adherence to these guidelines will help ensure a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk