

Seater Head 9,30/.366-R35

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-R35
- Manufacturer: TRIEBEL
- Product no.: EU2017508
- Mfr. No.: 3000054V-09.30-R035
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R35
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R035

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366R35. This product is designed for precise and gentle bullet seating, ensuring optimal accuracy in your reloading process. To ensure safe usage and compliance with EU regulations, please read this safety instruction guide carefully.

General Safety Guidelines

- **Product Safety:** Ensure the safe use of the Seater Head by following all instructions and safety precautions.
- **Enhanced Recalls:** Stay informed about any potential recalls by checking the EU's Safety Gate platform regularly.
- **Online Shopping:** If purchased online, ensure that the seller complies with safety requirements similar to physical stores.
- **Special Consumer Focus:** Extra caution should be taken if the product is used in environments with children or vulnerable individuals.
- **EU Contact Point:** For any safety inquiries, please reach out to the designated EU-based contact point provided by the manufacturer.
- **Rapid Alerts:** Keep updated on product safety alerts through the Safety Gate system.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper use may lead to misalignment of bullets, affecting accuracy and safety.
 - Always check for wear and tear on the Seater Head before use.
- **Avoiding Hazards:**
 - Always use the Seater Head with compatible dies from Triebel Waffenwerkzeuge.
 - Ensure that the Seater Head is securely attached to the reloading press before use.
 - Do not exceed the recommended specifications for the Seater Head.
- **Age-Specific Warnings:**
 - This product is intended for use by individuals aged 18 and older. Keep out of reach of children.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is unplugged to avoid accidental activation.
- Securely attach the Seater Head to the reloading press, ensuring it is tightened properly.
- Verify that the Seater Head is aligned correctly with the die.

2. Usage:

- Before starting, double-check that all components are in good condition and properly assembled.
- Load the cartridge case into the reloading press.
- Insert the bullet into the cartridge case and activate the press to seat the bullet.
- Monitor the process to ensure proper alignment and seating depth.

3. **PostUsage:**

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a dry and secure location to prevent damage.

Disposal Instructions

- Dispose of the Seater Head responsibly according to local regulations.
- Do not dispose of the Seater Head in household waste.
- Check with local recycling centers for proper disposal methods for brass and metal components.

Contact Information for Further Support

For further assistance or safety inquiries, please refer to the manufacturer's contact information provided on the official website.

By following these guidelines, you can ensure the safe and effective use of the Seater Head 9,30/.366R35. Thank you for prioritizing safety in your reloading processes.