

Seater Head 9,30/.366-R39

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-R39
- Manufacturer: TRIEBEL
- Product no.: EU2017509
- Mfr. No.: 3000054V-09.30-R039
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R39
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R039

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366R39 by TRIEBEL. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this document carefully before using the Seater Head to understand how to operate it safely and responsibly.

General Safety Guidelines

- Ensure that the Seater Head is only used with compatible original dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for damage or wear before each use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head in a wellventilated area to avoid inhalation of any dust or particles generated during use.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when operating the Seater Head.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Risk of injury from sharp edges or moving parts.
 - Risk of misalignment leading to improper bullet seating.
- **Avoiding Hazards:**
 - Handle the Seater Head with care and avoid contact with sharp edges.
 - Ensure that the Seater Head is properly aligned before use to prevent accidents.
- **AgeSpecific Warnings:**
 - This product is not intended for use by individuals under the age of 18 without adult supervision.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is securely mounted and stable.
- Insert the Seater Head into the compatible die according to the manufacturer's instructions.
- Tighten the die lock ring to secure the Seater Head in place.

2. Usage:

- Adjust the Seater Head to the desired seating depth as per your specifications.
- Place a cartridge case into the reloading press and engage the handle slowly to seat the bullet.
- Monitor the seating process closely to ensure proper alignment and depth.
- Remove completed cartridges from the press and inspect them for quality and consistency.

3. PostUsage Care:

- Clean the Seater Head after each use to remove any residue or debris.
- Store the Seater Head in a dry, safe place away from moisture and direct sunlight.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of the Seater Head in regular household waste.

- Consider recycling options for brass materials where available.

Contact Information for Further Support

For any inquiries related to safety or product support, please refer to the manufacturer's website at www.tribelreloading.com. It is important to stay informed about any safety updates or recalls through the EU's Safety Gate platform.

By following these guidelines, you can ensure a safe and effective experience using the Seater Head 9,30/.366R39. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.