

## Seater Head 9,50/.375-R41

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: Seater Head 9,50/.375-R41
- Manufacturer: TRIEBEL
- Product no.: EU2017515
- Mfr. No.: 3000054V-09.50-R041
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R41
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R041

# Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 9,50/.375R41 by TRIEBEL. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

## General Safety Guidelines

- Always ensure that you are using the product in accordance with the manufacturer's specifications.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Use the product only for its intended purpose to avoid accidents and injuries.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may lead to inaccurate bullet seating, affecting firearm performance.
- Risk of injury if the product is damaged or misused.

- **Avoiding Hazards:**

- Use only with original dies from Triebel Waffenwerkzeuge to ensure compatibility.
- Do not exceed the recommended specifications for diameter and radius.
- Always wear appropriate safety gear, including eye protection, when using the product.

- **AgeSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18.
- Ensure that only qualified adults operate and handle the product.

## Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading setup is clean and free of debris.
2. Select the appropriate seater head using the tool on the manufacturer's website: [www.triebelreloading.com](http://www.triebelreloading.com).
3. Install the seater head securely into the die according to the manufacturer's instructions.

- **Usage:**

1. Verify that the reloading press is set up correctly and is functioning properly.
2. Place the cartridge case in the press and ensure it is properly aligned.
3. Gently lower the seater head onto the bullet, applying consistent pressure.
4. Monitor the seating depth and adjust as necessary for optimal results.
5. After use, clean the seater head and store it in a safe place.

## **Disposal Instructions**

- Dispose of the product in accordance with local regulations for metal recycling.
- Do not dispose of the product in household waste.
- If the product is damaged or no longer usable, contact local recycling centers for proper disposal methods.

## **Contact Information for Further Support**

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact their customer support.