

Seater Head 9,50/.375-R105

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,50/.375-R105](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017520
- Mfr. No.: 3000054V-09.50-R105
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R105
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R105

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R105. This guide provides essential safety instructions to ensure the safe use of this product. Please read this guide carefully before using the Seater Head to maximize safety and performance.

General Safety Guidelines

- Ensure that the Seater Head is used only in conjunction with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Inspect the Seater Head regularly for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding ammunition reloading and handling.

Specific Safety Precautions for Use

- **Hazard Identification:** Improper use of the Seater Head can lead to misalignment of bullets, which may cause dangerous malfunctions during firing.
- **Avoiding Hazards:**
 - Always ensure that the Seater Head is securely attached to the reloading press before use.
 - Do not exceed the recommended specifications for bullet diameter and type.
 - Use the correct seater head for the specific bullet profile to ensure proper alignment.
 - Never attempt to modify or alter the Seater Head for any reason.
- **AgeSpecific Warning:** This product is not intended for use by individuals under the age of 18. Ensure that all users are of legal age and have proper training in reloading practices.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Clean the area where the Seater Head will be installed to remove any debris.
- Securely attach the Seater Head to the reloading press, following the manufacturer's instructions.
- Verify that the Seater Head is properly aligned before proceeding.

2. Usage:

- Prepare your cartridge cases and bullets according to the reloading guidelines.
- Insert the cartridge case into the reloading press and ensure it is seated correctly.
- Select the appropriate bullet for the Seater Head and place it on top of the cartridge case.
- Gradually lower the ram of the reloading press to seat the bullet. Monitor the process to ensure alignment.
- Once the bullet is seated, inspect the cartridge for proper seating and alignment before removing it from the press.

Disposal Instructions

- Dispose of the Seater Head and any associated components in accordance with local regulations for metal recycling.
- Do not dispose of the Seater Head in regular household waste.

- Ensure that all components are properly cleaned and free of any hazardous materials before disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact an authorized dealer.

By following these safety instructions, you will ensure a safe and effective reloading experience. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk