

Seater Head 9,50/.375-R125

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,50/.375-R125](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017522
- Mfr. No.: 3000054V-09.50-R125
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R125
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R125

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head 9,50/.375R125](#)
- [About Us](#)

Safety Instruction Guide for Seater Head 9,50/.375R125

Introduction

Thank you for choosing the Seater Head 9,50/.375R125. This product is designed for precise and gentle bullet seating, ensuring optimal performance in your reloading activities. To ensure safe and effective use, please read this safety instruction guide thoroughly before using the product.

General Safety Guidelines

- Always prioritize safety when using reloading equipment.
- Ensure that all products are used in accordance with the manufacturer's guidelines.
- Be aware of the potential hazards associated with the use of reloading tools, including but not limited to:
 - Risk of injury from sharp edges or moving parts.
 - Risk of damage to the equipment if used incorrectly.
 - Risk of improper bullet seating affecting accuracy and safety.
- Always store the Seater Head in a safe and dry place when not in use.
- Keep the product out of reach of children and vulnerable individuals.

Specific Safety Precautions for Use

- Before using the Seater Head, inspect it for any signs of damage or wear.
- Wear appropriate personal protective equipment (PPE), such as safety glasses, when using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Ensure that your reloading setup is stable and secure before beginning the reloading process.
- Follow all local laws and regulations regarding ammunition reloading and safety.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Carefully attach the Seater Head to your reloading die, making sure it is securely fastened.
- Refer to the manufacturer's website for specific installation instructions tailored to your equipment.

2. Usage:

- Set the desired bullet seating depth according to your reloading specifications.
- Place the cartridge case into the reloading press and align it with the Seater Head.
- Slowly and steadily operate the press to seat the bullet. Avoid rushing the process to ensure accuracy.
- After seating, inspect the cartridge for proper bullet alignment and depth.

3. PostUsage:

- Clean the Seater Head after use to maintain its precision and longevity.
- Store the Seater Head in its original packaging or a secure location to prevent damage.

Disposal Instructions

- When disposing of the Seater Head, follow local regulations for the disposal of metal products.
- Do not dispose of the product in regular household waste.
- Consider recycling options available in your area to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or further assistance, please consult the manufacturer's website at www.triebelreloading.com. It is important to ensure that you have access to the latest safety updates and product information.

By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 9,50/.375R125. Always prioritize safety and consult with experts if you have any questions or concerns regarding the use of this product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk