

Seater Head 10,30/.413-R31

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,30/.413-R31
- Manufacturer: TRIEBEL
- Product no.: EU2017528
- Mfr. No.: 3000054V-10.30-R031
- Diameter (in): 0.413
- Diameter mm: 10,30
- Radius: R31
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.30-R031

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,30/.413R31. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow this safety instruction guide carefully.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always handle the Seater Head with care to avoid injury.
- Keep the product away from children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use the product in a wellventilated area to avoid inhalation of any dust or debris.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Before using the Seater Head, ensure that you are familiar with the reloading process and the equipment involved.
- Always wear appropriate safety gear, including eye protection and gloves, when handling reloading components.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Avoid exceeding the recommended specifications for bullet seating to prevent potential accidents.
- If you experience any malfunction or unusual behavior while using the Seater Head, stop using it immediately and consult a professional.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to choose the appropriate seater head for your needs.

2. Installation:

- Ensure that the reloading die is clean and free from debris.
- Carefully attach the Seater Head to the reloading die, ensuring a secure fit.
- Check that the Seater Head is aligned properly to allow for optimal bullet seating.

3. Usage:

- Place the cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring it is properly aligned with the Seater Head.
- Slowly and steadily operate the reloading press to seat the bullet, monitoring for any resistance or issues.
- After seating, remove the cartridge and inspect for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Check for recycling options or hazardous waste disposal facilities in your area.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website for contact information and support resources.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the Seater Head 10,30/.413R31. Stay informed about product recalls and safety updates through the EU's Safety Gate platform. Thank you for prioritizing safety in your reloading activities.