

Seater Head 10,36/.408-R165

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,36/.408-R165](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017536
- Mfr. No.: 3000054V-10.36-R165
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R165
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R165

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head 10,36/.408R165](#)
- [About Us](#)

Safety Instruction Guide for Seater Head 10,36/.408R165

Introduction

Thank you for choosing the Seater Head 10,36/.408R165. This product is designed to enhance your reloading experience by providing precise and gentle bullet seating. To ensure your safety and maximize the effectiveness of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Always handle reloading equipment with care to avoid accidents and injuries.
- Keep the product out of reach of children and unauthorized users.
- Regularly check for wear or damage to the Seater Head and replace it if necessary.
- Be aware of your surroundings when using this product to prevent accidents.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Improper use of the Seater Head may lead to misalignment of bullets, resulting in inaccurate ammunition.
 - There is a risk of injury if the Seater Head is not securely attached to the reloading press.
- **Avoiding Hazards:**
 - Always ensure that the Seater Head is properly installed before use.
 - Do not exceed the recommended specifications for bullet diameter and seating depth.
 - Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
 - Wear safety goggles and gloves while reloading to protect against potential hazards.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading press is turned off and unplugged.
 2. Carefully remove the existing seater head from your die.
 3. Align the Seater Head with the die and securely tighten it in place.
 4. Doublecheck that the Seater Head is firmly attached before proceeding.
- **Usage:**
 1. Select the correct bullet for your reloading needs, ensuring it matches the Seater Head specifications.
 2. Insert the cartridge case into the reloading press.
 3. Adjust the seating depth according to your specifications.
 4. Operate the reloading press to seat the bullet gently and accurately.
 5. Regularly inspect the seated bullets for proper alignment and depth.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Do not throw the product in regular household waste; check for recycling options in your area.
- Ensure that all parts are disposed of safely to prevent environmental harm.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the official website of the manufacturer. It is important to have access to professional guidance if you have any questions or concerns about your Seater Head.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head 10,36/.408R165.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk