

Seater Head 10,57/.416-K18,6

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-K18,6](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017539
- Mfr. No.: 3000054V-10.57-K18.6
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: K18,6
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-K18.6

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head Seater Head 10,57/.416K18,6](#)
- [About Us](#)

Safety Instruction Guide for Seater Head Seater Head 10,57/.416K18,6

Introduction

Thank you for choosing the Seater Head Seater Head 10,57/.416K18,6. This product is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the product according to the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you notice any defects, do not use the product and contact the manufacturer.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that you are using the correct seater head for your specific reloading dies.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling ammunition components.
- Avoid working in a cluttered or poorly lit environment.
- Do not exceed the recommended specifications for the product, as this may lead to accidents.
- Follow proper handling and storage procedures for all reloading materials.
- Be aware of the potential hazards associated with reloading, including the risk of injury from sharp objects and the risk of fire or explosion from improper handling of powder and primers.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Visit the manufacturer's website at www.triebelreloading.com.
- Use the provided tool to select the appropriate seater head for your needs.

2. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the die.
- Carefully install the Seater Head Seater Head 10,57/.416K18,6 by following the die manufacturer's instructions.
- Tighten the seater head securely but do not overtighten, as this may cause damage.

3. Usage:

- Set the desired bullet seating depth according to your reloading specifications.
- Insert the cartridge case into the reloading press.
- Operate the press smoothly and steadily to seat the bullet.
- Inspect each cartridge for proper seating before proceeding to the next.

4. PostUse Care:

- Clean the seater head after use to remove any debris or residue.
- Store the product in a dry and safe place, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.
- Consider recycling options where available, especially for metal components.

Contact Information for Further Support

For any inquiries or support regarding the Seater Head Seater Head 10,57/.416K18,6, please refer to the manufacturer's website or contact their customer service.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head Seater Head 10,57/.416K18,6. Thank you for prioritizing safety and compliance with EU regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk